



ATevo Communications

1.1 — Last update: 25 October 2023

HindlePower Inc

Table of Contents

- 1. Introduction 4
- 2. Protocols..... 6
- 3. Hardware 7
 - 3.1. Serial Communications Adapter Option 8
 - 3.1.1. Serial Communications Adapter Installation 9
 - 3.1.2. RS-232 11
 - 3.1.3. 3-Wire RS-232 Connections 12
 - 3.1.4. 5-Wire RS-232 Connections 14
 - 3.1.5. RS-485 16
 - 3.1.6. 2-Wire RS-485 Connections 17
 - 3.1.7. 4-Wire RS-485 Connections 19
 - 3.1.8. Optional Serial Fiber Modems 21
 - 3.2. Ethernet Communications Adapter Option 22
 - 3.2.1. Ethernet Communications Adapter Installation 23
 - 3.2.2. Ethernet Defined 25
 - 3.2.3. Ethernet Connections 26
 - 3.2.4. Optional Fiber Ethernet Interface 27
- 4. Configuration 28
 - 4.1. Serial Communications Configuration 29
 - 4.1.1. Assigning PORT Protocol 30
 - 4.1.2. Changing Common Serial PORT Parameters 31
 - 4.1.3. Changing Modbus Serial PORT Parameters 34
 - 4.1.4. Changing DNP3 Serial PORT Parameters 35
 - 4.2. Ethernet Communications Configuration 38
 - 4.2.1. Enabling Ethernet Adapter 39
 - 4.2.2. Changing Common Ethernet Parameters 40
 - 4.2.3. Enable/Disable Modbus Communications via Ethernet 42
 - 4.2.4. Configuring Modbus Ethernet Parameters 43
 - 4.2.5. Enable/Disable DNP Communications via Ethernet 44
 - 4.2.6. Configuring DNP Ethernet Parameters 45
- 5. DNP3 48
 - 5.1. Introduction to DNP3 49
 - 5.2. Device Profile Document 50
 - 5.3. Implementation Table 54
 - 5.4. DNP Point Lists 60
 - 5.4.1. Binary Input Points 61
 - 5.4.2. Binary Output Points 64
 - 5.4.3. Analog Input Status Points 65

- 5.4.4. Analog Output Status Points 68
- 5.4.5. Internal Indication (IIN) Bits 71
- 6. Modbus..... 73**
 - 6.1. Introduction to Modbus 74
 - 6.2. Supported Function Codes..... 75
 - 6.3. Modbus Binary Outputs (Coils) 76
 - 6.4. Binary Inputs..... 77
 - 6.5. Modbus Input Registers 80
 - 6.6. Modbus Holding Registers 82
- 7. Appendix - Document Control Information 85**
- 8. SAFETY 87**

1. Introduction

p/n JA0102-54

* The page breaks & formatting, as well as start & end sections, of this online variant of the *ATevo Communications Module Instructions* may differ slightly compared to the paper hard copy included in your battery charger manual pocket. For an Adobe PDF digital copy of that manual, access the following link ([JA0102-54](#)).

BEFORE YOU START

- Familiarize yourself with ALL **SAFETY** Instructions.

SECTION TOPICS
Introduction
Protocols
Hardware
Configuration
DNP3
Modbus
Appendix - Document Control Information
SAFETY

1.1 Overview

The ATevo Communications options allow users to remotely observe any status, or perform any function, that is accessible at the battery charger's front panel display.

Two (2) 'communications' option boards, supporting both DNP3 Level 2 and Modbus SCADA protocols, are available:

- Serial Communications Adapters (A12), supporting BAUD rates from 9600 to 115.2K for:
 - 3-wire or 5-wire RS-232 connections
 - 2-wire or 4-wire RS-485 connections
- Ethernet Communications Adapter (A22), supporting standard RJ-45 10/100 Mbps copper Ethernet connections

1.1.1 Forced Load Sharing

The ATevo Forced Load Sharing option similarly utilizes a Serial Communications Adapter (A13). For detailed information on Forced Load Sharing, refer to instructions ([JA5054-50](#)), or Section 13 of the main ATevo 'battery charger' Operating & Service Instructions manuals ([JA0102-51](#), [JA0102-52](#), or [JA0102-53](#)).

1.1.2 Limitations

The ATevo Communications provides users remote access to all battery charger functionality. Only battery charger controls (user input) and charger status (ATevo output) are accessible.

✿ At the time of publishing this manual, a remote graphical user interface (GUI) or a human-machine interface (HMI) is not supplied nor supported by the manufacturer of ATevo. These types of interfaces are sometimes provided by third parties.

1.1.3 ATevo Set Points & Firmware Defaults

Certain entries in the DNP ([Section 5](#)) & Modbus ([Section 6](#)) points tables are dependent on ATevo battery charger model. Ranges differ, depending on nominal output voltage (24, 48, 130, or 260 Vdc).

For a complete listing of these settings, download the latest revision of the ATevo Set Points & Firmware Defaults ([JA5124-02](#)).

Last modified: 25 October 2023

2. Protocols

2.1 DNP3 Overview

Communications options support DNP3 Level 2 protocol and change events with unsolicited messaging.

Serial Settings Supported		
Parity	Data Bits	Stop Bits
no	8	1
no	8	2
even	8	1
odd	8	1

Refer to [Section 5](#) regarding DNP3 protocol and point list.

2.2 Modbus Overview

Communications options can be set to communicate on standard Modbus networks using either of two transmission modes:

Transmission Mode	Advantage of Mode	Serial Settings Supported		
		Parity	Data Bits	Stop Bits
ASCII	less strict serial timing requirements without causing errors	no	7	2
		even	7	1
		odd	7	1
RTU	higher throughput than ASCII due to more data transmission with less overhead	Parity	Data Bits	Stop Bits
		no	8	1
		no	8	2
		even	8	1
		odd	8	1

Refer to [Section 6](#) regarding Modbus protocol and register set.

Last modified: 25 October 2023

3. Hardware

SECTION TOPICS
Serial Communications Adapter Option
Ethernet Communications Adapter Option

Last modified: 23 October 2023

3.1. Serial Communications Adapter Option

ATevo Communications can support up to three (3) Serial Communications Adapters supporting connections to either RS-232 or RS-485 networks. Serial Adapter hardware must be configured correctly before connecting to the network.


The following pages discuss the Serial Communications Adapters:

- [Serial Communications Adapter Installation](#)
- [RS-232](#)
- [3-Wire RS-232 Connections](#)
- [5-Wire RS-232 Connections](#)
- [RS-485](#)
- [2-Wire RS-485 Connections](#)
- [4-Wire RS-485 Connections](#)
- [Optional Serial Fiber Modems](#)

Last modified: 23 October 2023

3.1.1. Serial Communications Adapter Installation

Each Serial Adapter is configured independently and can be set to connect to different network types. Serial Communications Adapters can be plugged into “PORT 1” (P10), “PORT 2” (P11), and/or “PORT 3” (P12) located along the left side of the Main Control Board. Both PORT 2 (P11) and PORT 3 (P12) will support DNP3 and Modbus protocols.



To install a Serial Communications Adapter:

1. Turn off (open) both AC Input (CB1) and DC Output (CB2) Circuit Breakers.
2. Wait for the ATevo dc voltage to ramp down (display will go blank and all LEDs will be off).
3. Open ATevo front panel door.
4. Remove ground connection from lower-left corner of the Main Control Board (A1).
5. Carefully disengage the Main Control Board (A1) from the left side standoffs.
6. Make sure you correctly configured settings for Serial Communications Adapter Boards (see [Sections 3.1.2](#) through [3.1.7](#)).
7. Locate the Serial Communications Adapter connection ports (P10, P11, & P12) along the left side of Main Control Board (A1).
8. Carefully slide socket (P1) of the Serial Communications Adapter onto pins of one (1) connection port (P10, P11, or P12) of the Main Control Board. For Modbus or DNP3, use P11 or P12.
9. Hold the Serial Communications Adapter at an angle to clear standoffs on the front panel door.

10. Once the Serial Communications Adapter socket is fully engaged on the Main Control Board header pins, line up the hole on the Serial Connection Board with the plastic standoff pin.
11. Press down on the Serial Communications Adapter and the Main Control Board to lock them onto the standoffs.
12. Replace the ground connection on the bottom-left side of the Main Control Board.
13. Make note of which numbered port (2 or 3 for Modbus or DNP3), to which the Serial Communications Adapter is now connected.
14. Close the ATevo front panel door.
15. Turn on (close) the AC Input Circuit Breaker (CB1), then close the DC Output Circuit Breaker (CB2).
16. The Serial Communications Adapter hardware is now installed.
17. Refer to [Section 4.1](#) to assign a protocol and configure communications parameters (baud rate, parity, etc).

Last modified: 24 October 2023

3.1.2. RS-232

RS-232 is a standard for serial data transmission. It is commonly used in pc serial ports for connections to modems, mice, and printers. It only permits two (2) devices to be connected together, has a limited cable distance, and is more susceptible to electrical noise than RS-485 networks.


The next 2 pages discuss RS-232:

- [3-Wire RS-232 Connections](#)
- [5-Wire RS-232 Connections](#)

Last modified: 23 October 2023

3.1.3. 3-Wire RS-232 Connections

To make connections and configure settings for 3-Wire connections between the Serial Adapter and an RS-232 network, use the following diagram and tables:




3-Wire RS-232 Settings		
Jumper(s)	Label	Setting
P3	MEDIA	232
P6, P7	#WIRES	4W
P2	RXCTRL	ON
P4, P5	485-TERM	OFF

Wiring Serial Adapter to RS-232 Network		
Adapter	to	RS-232
RXD (TB1-1)	to	TXD
TXD (TB1-2)	to	RXD
GND (TB1-5)	to	COM

3.1.4. 5-Wire RS-232 Connections

To make connections and configure settings for 5-Wire connections between the Serial Adapter and an RS-232 network, use the following diagram and tables:



5-Wire RS-232 Settings		
Jumper(s)	Label	Setting
P3	MEDIA	232
P6, P7	#WIRES	4W
P2	RXCTRL	ON
P4, P5	485-TERM	OFF

Wiring Serial Adapter to RS-232 Network		
Adapter	to	RS-232
RXD (TB1-1)	to	TXD
TXD (TB1-2)	to	RXD
CTS (TB1-3)	to	RTS
RTS (TB1-4)	to	CTS

GND (TB1-5)	to	COM
-------------	----	-----

Last modified: 23 October 2023

3.1.5. RS-485

RS-485 is a standard, defining electrical characteristics of drivers and receivers for use in balanced digital multipoint systems. RS-485 networks can be used effectively over long distances in electrically noisy industrial environments. Multiple devices may be connected to the same network.

Some RS-485 networks may require termination resistors at both ends of the serial network. The decision of whether or not to use termination resistors should be based on the BAUD rate, the cable distance, and the type of cable being used to build the network. In most cases for BAUD rates less than 19.2K, termination resistors are not required. If termination resistors are used, the network must be designed with the appropriate biasing resistors to ensure reliable communications.

Biasing resistors ensure that the network remains in idle state when all drivers are tri- stated. To guarantee that the receivers remain in a known state, $\pm 200\text{mV}$ must be maintained across the RS-485 inputs, (A) or (-) and (B) or (+). When termination resistors are used, this requires a significantly lower value of biasing resistors which results in greater dc loading of the network.

Network design and biasing resistor calculations depend on the number of network nodes, the type of drivers and receivers on the network, and any biasing already designed into other devices sharing the network. As a result, termination resistor decisions and biasing resistor calculations are beyond the scope of this manual. For more information on biasing and termination details see the following references:

- TIA-485 Electrical Characteristics of Generators and Receivers for Use in Balanced Digital Multipoint Systems,
 - <https://global.ihs.com>
- RS-422/RS-485 Application Note Copyright: B&B Electronics
 - <http://www.ATSeries.net/PDFs/RS422+485AppNote.pdf>

The Serial Communications Adapter board features configurable 120 Ohm termination resistors. Jumpers P4 and P5 enable or disable the terminating resistors.


The next 2 pages discuss RS-485:

- [2-Wire RS-485 Connections](#)
- [4-Wire RS-485 Connections](#)

Last modified: 23 October 2023

3.1.6. 2-Wire RS-485 Connections

To make connections and configure settings for 2-Wire connections between the Serial Adapter and an RS-485 network, use the following diagram and tables:



2-Wire RS-485 Settings		
Jumper(s)	Label	Setting
P3	MEDIA	485
P6, P7	#WIRES	2W
P2	RXCTRL	TXE
P4, P5	485-TERM	OFF

! If you want to utilize the on-board termination resistor located on the Serial Adapter, set “P5” to the “ON” position. Termination resistors should only be placed on the extreme ends of the network (2 devices only). In addition, the network must be biased correctly or the termination resistors may cause communications errors.

Wiring Serial Adapter to RS-485 Network		
Adapter	to	RS-485


A- (TB1-1)	to	A-
B+ (TB1-3)	to	B+
GND (TB1-5)	to	COM

- * When set to "2W", P6 connects TB1-1 to TB1-2.
When set to "2W", P7 connects TB1-3 to TB1-4.

Last modified: 24 October 2023

3.1.7. 4-Wire RS-485 Connections

To make connections and configure settings for 4-Wire connections between the Serial Adapter and an RS-485 network, use the following diagram and tables:



4-Wire RS-485 Settings		
Jumper(s)	Label	Setting
P3	MEDIA	485
P6, P7	#WIRES	4W
P2	RXCTRL	ON
P4, P5	485-TERM	OFF

! To utilize the on-board termination resistors located on the Serial Adapter, set “P5” & “P6” to the “ON” position. Termination resistors should only be placed on the extreme ends of the network (2 devices only). In addition, the network must be biased correctly or the termination resistors may cause communications errors.

Wiring Serial Adapter to RS-485 Network		
Adapter	to	RS-232
RA- (TB1-1)	to	TA-

TA- (TB1-2)	to	RA-
RB+ (TB1-3)	to	TB+
TB+ (TB1-4)	to	RB+
GND (TB1-5)	to	COM

Last modified: 23 October 2023

3.1.8. Optional Serial Fiber Modems

Several optional serial converters are available for ATevo. When ordered, these options will be factory-installed, and allow direct connection of fiber optics compatible with standard “B&B” and “DYMEC” type converters. Refer to the following supplemental documents for the available Fiber Optics Interface options.

Fiber Optics Interface Options	
Interface P/N	Supplemental Documentation
EJ5230-5#	“B&B” Fiber Optics Interface for ATevo
EJ5230-6#	“DYMEC” RS485 Fiber Optics Interface for ATevo
EJ5230-7#	“DYMEC” RS232 Fiber Optics Interface for ATevo

Last modified: 24 October 2023

3.2. Ethernet Communications Adapter Option

ATevo Communications can support one (1) Ethernet Comm Adapter (A22). The adapter contains a standard RJ-45 connector and will support copper 10/100 Mbps Ethernet connections. It supports multiple protocols (DNP3 and Modbus) simultaneously.


The following pages discuss the Ethernet Communications Adapter:

- [Ethernet Communications Adapter Installation](#)
- [Ethernet Defined](#)
- [Ethernet Connections](#)
- [Optional Fiber Ethernet Interface](#)

Last modified: 23 October 2023

3.2.1. Ethernet Communications Adapter Installation

The Ethernet Communications Adapter (A22) plugs into the “Ethernet” port (P13), near the bottom-left of the Main Control Board.



To install an Ethernet Communications Adapter:

1. Turn off (open) both AC Input (CB1) and DC Output (CB2) Circuit Breakers.
2. Wait for charger voltage to ramp down (display will go blank and all LEDs will be off).
3. Open the ATevo front panel door.
4. Remove the ground connection from the lower-left corner of the Main Control PC Board (A1).
5. Carefully disengage the Main Control Board from standoffs on the left side of the board.
6. Locate the Ethernet Communications Adapter connection port (P13), near the bottom-left of the Main Control Board (A1).
7. Carefully slide socket (P1) of the Ethernet Communications Adapter onto pins of connection port (P13) of the Main Control Board.
8. Hold the Ethernet Communications Adapter (A22) at an angle to clear standoffs on the door.
9. Once the Ethernet Communications Adapter socket is fully engaged on the Main Control Board header pins, line up the holes on the Ethernet Adapter (A22) with the plastic standoff pins.
10. Press down on the Ethernet Communications Adapter (A22) and the Main Control Board

(A1) to lock them onto the standoffs.

11. Replace the ground connection on the bottom-left side of the Main Control Board.
12. Close the ATevo front panel door.
13. Turn on (close) the AC Input Breaker (CB1), then turn on (close) the DC Output Breaker (CB2).
14. The Ethernet Communications Adapter hardware is now installed.
15. Refer to [Section 4.2](#) to assign protocol and set communications parameters (IP address, Netmask, Gateway, etc).

Last modified: 23 October 2023

3.2.2. Ethernet Defined

Ethernet is a family of computer networking technologies used in local area networks (LANs). Several variants of Ethernet are available. Newer variants typically use copper twisted-pair or fiber optic links with hubs or switches to form the network. Ethernet permits a large number of devices to be interconnected and allows the devices to communicate via multiple protocols concurrently.

Last modified: 23 October 2023

3.2.3. Ethernet Connections

ATevo Communications can be connected to a 10/100 Mbps Ethernet network with a standard Ethernet RJ-45 cable. Plug one end of the cable into J1 of the Ethernet Adapter (A22) and the other end into an Ethernet hub, switch or directly into the SCADA master.

Last modified: 23 October 2023

3.2.4. Optional Fiber Ethernet Interface


Although Ethernet interfaces are standardized, many variants of Ethernet over fiber exist (75 at the time this manual was written). The variants are based on different data rates, fiber type, wavelength, and connector types.

The optional ATevo Fiber Ethernet Interface can be configured to accommodate most if not all of these variants. Due to the vast number of variants (and continuous addition of new ones), the specific offerings and capabilities needed to interface a site fiber Ethernet network must be verified with an ATevo distributor.

Last modified: 23 October 2023

4. Configuration

To configure Serial (A12) Communications Adapters, select MENU > COMMUNICATION. The ATevo will display the ports that may be configured.



To change settings for an adapter, do the following:

1. Navigate to it using UP and DOWN; select it with EDIT/ENTER.
2. Press UP and DOWN to navigate to parameter to configure.
3. Press EDIT/ENTER to select parameter.
4. For numbers, use LEFT and RIGHT to navigate to digit to edit, then UP and DOWN to change digit value, then EDIT/ENTER to store new value.
5. If options presented, use UP and DOWN to select, then EDIT/ ENTER to store new option.

As discussed in [Section 3.3.3 of the ATevo Operations Manual](#), all commands in this manual are also presented with a shorthand communication:

Command > Command > Command

This sample omits navigation buttons like UP, LEFT, and ENTER.

SECTION TOPICS

[Serial Communications Configuration](#)

[Ethernet Communications Configuration](#)

Last modified: 24 October 2023

4.1. Serial Communications Configuration

Before configuring the ATevo Serial Communications Adapters, refer to [Section 3.1](#) to make sure the hardware jumper settings on the cards are correct for your application.


- * A Serial Communications Adapter must be installed in the associated PORT in order for that port to be operational. Any PORT without a Serial Communications Adapter must be set up as “Unconfigured” (appears as “none”). See [Section 3.1.1](#) for details on installing communications adapters.

Last modified: 23 October 2023

4.1.1. Assigning PORT Protocol

When configuring a PORT, set the protocol first. If a serial PORT is not assigned a protocol, “(none)” will appear next to the PORT name. If the Serial PORT is already assigned a protocol, see [Section 4.1.2](#) for instructions on how to change the PORT configuration.

To assign a protocol to an unassigned serial PORT: MENU > COMMUNICATION (as shown in [Section 4](#)) > select unassigned port > any key > select protocol



Last modified: 24 October 2023


4.1.2. Changing Common Serial PORT Parameters

Several serial PORT configuration parameters are used by all protocols. Other parameters are used only by specific protocols. This section specifies configuration of parameters used by all protocols.

✿ First assign protocol to port per [Section 4.1.1.](#)


To change the protocol assigned to a port:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port with assigned protocol > "Protocol:" > select from choices




To change Baud Rate:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port with assigned protocol > "Baud rate:" > select from choices




To change parity:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port with assigned protocol > "Parity:" > select from choices




To change the number of Stop bits:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port with assigned protocol > "Stop bits:" > change digits



To change handshake setting:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port with assigned protocol > "Handshake:" > select from choices



- ✿ It is strongly suggested that Handshake be set to “none”. Handshaking is never used in RS-485 applications, and it is rarely used in RS-232 applications. It was used years ago with older dial-up modems.

Last modified: 24 October 2023

4.1.3. Changing Modbus Serial PORT Parameters


This section describes how to change serial port configuration parameters used by Modbus protocol. Refer to [Section 4.1.2](#) to change parameters common to all protocols.

* Modbus must have already been assigned as port's protocol per [Section 4.1.1](#) or [4.1.2](#).

Modbus protocols require a unique device ID address from 1 to 247.

To change the Modbus ID address:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port with "Modbus" protocol > "Address:" > set digits



Last modified: 24 October 2023

4.1.4. Changing DNP3 Serial PORT Parameters


This section details how to change serial port configuration parameters used by the DNP3 protocol. Refer to [4.1.2](#) to change parameters common to all protocols.

- * DNP must have already been assigned as port's protocol per [Section 4.1.1](#) or [4.1.2](#).

DNP3 protocol requires a unique device source address from 1 to 65535 and specific configuration parameters associated with the unsolicited response feature.

To change the DNP source address:


MENU > COMMUNICATION (as shown in [Section 4](#)) > select port with "Modbus" protocol > "Address:" > set digits



To enable or disable DNP unsolicited responses:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port with "DNP" protocol > "Unsolicited:" > select option


- * Unsolicited responses are rarely used in DNP protocols. Before enabling unsolicited responses check with the network administrator to make sure the network is capable of supporting DNP unsolicited responses.



* The remaining DNP parameters are only used when DNP unsolicited responses are enabled.


To change DNP unsolicited response destination address:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port using “DNP” protocol where unsolicited responses are enabled > “Destination address:” > change digits





To change DNP unsolicited response acknowledgement timeout:

MENU > COMMUNICATION (as shown in [Section 4](#)) > select port using “DNP” protocol where unsolicited responses are enabled > “Timeout ms:” > change digits (value is in milliseconds)



To change DNP number of unsolicited response retries:


MENU > COMMUNICATION (as shown in [Section 4](#)) > select port using “DNP” protocol where unsolicited responses are enabled > “Retries:” > change digits



Last modified: 24 October 2023

4.2. Ethernet Communications Configuration

To change or verify the ATevo Ethernet Communications Adapter Configuration:
MENU > COMMUNICATION > “Ethernet setup”



If “(none)” appears after “Ethernet setup”, the Ethernet adapter will need to be enabled according to instructions in [Section 4.2.1](#).


- * An Ethernet Communications Adapter (A22) is required for Ethernet communications to be operational. If one is not installed, the Ethernet configuration must be set to “disabled” (appears as “none”). See [Section 3.2.1](#) for details on installing communications adapters.

Last modified: 24 October 2023


4.2.1. Enabling Ethernet Adapter

The first step in configuring the Ethernet Adapter is to enable it. To enable the Ethernet Adapter:

MENU > COMMUNICATION > "Ethernet setup" (as shown in [Section 4.2](#)) > "enabled"



Ethernet configuration parameters will now appear. Refer to [Sections 4.2.2](#) to [4.2.6](#) for how to configure remaining Ethernet parameters.



Last modified: 24 October 2023


4.2.2. Changing Common Ethernet Parameters

Several Ethernet configuration parameters are used by all protocols; other parameters are used only by specific protocols. This section specifies configuration of parameters used by all protocols.

* The Ethernet Adapter (A22) must have been enabled per [Section 4.2.1](#).


To change the IP address:

MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “IP addr:” > change digits




To change the “Netmask:” selection:

MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “Netmask:” > change digits



To change the “Gateway Address”:

MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “Gateway:” > change digits




Last modified: 24 October 2023

4.2.3. Enable/Disable Modbus Communications via Ethernet

The ATevo Ethernet Adapter (A22) is capable of communicating via multiple protocols simultaneously. After enabling the Ethernet Adapter and checking common parameter configuration ([Sections 4.2.1](#) to [4.2.2](#)), you may enable/ disable Modbus communications:

To enable or disable Modbus communications via Ethernet:

MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “Modbus:” > select “enable” or “disable”




Last modified: 24 October 2023

4.2.4. Configuring Modbus Ethernet Parameters

Modbus Ethernet protocol requires configuration of the following specific parameters:

To change the Modbus Ethernet Port number:


MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “Port:” (located after “Modbus: enabled”) > change digits



* Default Modbus Ethernet Port is 502. It is highly recommended that this port number not be changed.

To change the Modbus ID address for the Ethernet interface:

MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “Address:” (located after “Modbus: enabled”) > change digits



Last modified: 24 October 2023


4.2.5. Enable/Disable DNP Communications via Ethernet

The ATevo Ethernet Adapter (A22) is capable of communicating via multiple protocols simultaneously.

After enabling the Ethernet adapter and checking common parameter configuration ([Sections 4.2.1 - 4.2.2](#)), you may enable/disable DNP communications:

To enable or disable DNP communications via Ethernet:

MENU > COMMUNICATION > "Ethernet setup" (as shown in [Section 4.2](#)) > "DNP:" > select "enable" or "disable"




Last modified: 24 October 2023

4.2.6. Configuring DNP Ethernet Parameters

DNP Ethernet protocol requires configuration of a number of DNP specific parameters.

To change DNP Ethernet Port number:


MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “Port:” (located after “DNP: enabled”) > change digits



* Default DNP Ethernet Port is 20000. It is highly recommended that this port number not be changed.

To change DNP source address for the Ethernet interface:

MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “Address:” (located after “DNP: enabled”) > change digits




To enable or disable DNP unsolicited responses for the Ethernet interface:

MENU > COMMUNICATION > “Ethernet setup” (as shown in [Section 4.2](#)) > “Unsolicited:” (located after “DNP: enabled”) > select “enabled” or “disabled”

* Unsolicited responses are rarely used in DNP protocols. Before enabling


unsolicited responses check with network administrator to make sure network is capable of supporting DNP unsolicited responses.



* Remaining DNP parameters are only used when Ethernet DNP unsolicited responses are enabled.


To change DNP unsolicited response destination address:

MENU > COMMUNICATION > "Ethernet setup" (as shown in [Section 4.2](#)) > "Unsol dest addr:" (located after "DNP: enabled") > change digits




To change DNP unsolicited response acknowledgement timeout:

MENU > COMMUNICATION > "Ethernet setup" (as shown in [Section 4.2](#)) > "Timeout ms:" (located after "DNP: enabled") > change digits



To change DNP number of unsolicited response retries for the Ethernet interface:
MENU > COMMUNICATION > "Ethernet setup" as shown in [Section 4.2](#) > "Retries:" (located after "DNP: enabled") > change digits



Last modified: 24 October 2023

5. DNP3

SECTION TOPICS
Introduction to DNP3
Device Profile Document
Implementation Table
DNP Point Lists

Last modified: 23 October 2023

5.1. Introduction to DNP3

This section provides specifics for implementing DNP3 Level 2 protocol via the ATevo Communications Adapters. In conjunction with the DNP3 Basic 4 Document Set, and the DNP Subset Definitions Document, it provides complete information on how to communicate to the battery charger via the DNP3 interface.

This implementation of DNP3 is fully compliant with DNP3 Subset Definition Level 2, contains many Subset Level 3 features, and contains some functionality beyond Subset Level 3.

Last modified: 23 October 2023

5.2. Device Profile Document

The following table provides a “Device Profile Document” in the standard format defined in the DNP3 Subset Definitions Document. This table, in combination with the following two (2) items, should provide a complete interoperability/configuration guide for the DNP3 interface on the ATevo Serial Communications (A12) and Ethernet (A22) Adapters:

- [Implementation Table - Section 5.3](#)
- [Point List Tables - Section 5.4](#)

DNP3 Device Profile Document			
Vendor Name: HindlePower, Inc. - 1075 Saint John Street - Easton, PA 18042			
Device Name: ATevo Communications Modules			
Highest DNP Level Supported		Device Function	
For Request	Level 2	-	Master
For Responses	Level 2	✓	Slave
Notable objects, functions, and/or qualifiers supported in addition to the Highest DNP Levels Supported (the complete list is described in the attached table):			
Maximum Data Link Frame Size (octets)		Maximum Application Fragment Size (octets)	
Transmitted	292	Transmitted	2048
Received	292	Received	2048
Maximum Data Link Re-tries		Maximum Application Layer Re-tries	
✓	None	✓	None
-	Fixed at 3	-	Configurable
-	Configurable range 0 - 255		
Requires Data Link Confirmation...			
✓	Never		
-	Always		
-	Sometimes		
-	Configurable		

Requires Application Layer Confirmation...								
-	Never							
-	Always							
✓	When reporting event data							
-	When sending multi-fragment responses							
-	Sometimes							
-	Configurable							
Timeouts While Waiting For...								
Data Link Confirm	-	None	✓	Fixed @ 2000	-	Variable	-	Configurable
Complete Appl. Fragment	✓	None	-	Fixed @ ____	-	Variable	-	Configurable
Application Confirm	-	None	✓	Fixed @ 2000	-	Variable	-	Configurable
Complete Appl. Response	✓	None	-	Fixed @ ____	-	Variable	-	Configurable

Others	
Inter-character Timeout	✓ Fixed @ 50ms
Select/Operate Arm Timeout	✓ Fixed @ 5000ms
Binary Input Change Scanning Period	✓ Fixed @ 5000ms
Analog Input Change Scanning Period	✓ Fixed @ 5000ms
Unsolicited Offline Interval	✓ Fixed @ 30000 ms if unsolicited responses is off. Configurable if unsolicited responses is on. See setup.
Unsolicited Response Notification Delay	✓ Fixed @ 15000ms
Delay Measurement	100ms
Synchronization	1000ms

Sends/Executes Control Operations								
WRITE Binary Outputs	<input type="checkbox"/>	Never	<input checked="" type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
SELECT/OPERATE	<input type="checkbox"/>	Never	<input checked="" type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
DIRECT OPERATE	<input type="checkbox"/>	Never	<input checked="" type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
DIRECT OPERATE - NO ACK	<input type="checkbox"/>	Never	<input checked="" type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
Count >1	<input checked="" type="checkbox"/>	Never	<input type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
Pulse On	<input checked="" type="checkbox"/>	Never	<input type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
Pluse Off	<input checked="" type="checkbox"/>	Never	<input type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
Latch On	<input type="checkbox"/>	Never	<input checked="" type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
Latch Off	<input type="checkbox"/>	Never	<input type="checkbox"/>	Always	<input checked="" type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
Queue	<input checked="" type="checkbox"/>	Never	<input type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable
Clear Queue	<input checked="" type="checkbox"/>	Never	<input type="checkbox"/>	Always	<input type="checkbox"/>	Sometimes	<input type="checkbox"/>	Configurable

Explanation of Sometimes: See the Binary Outputs point list in Section 4.3

Reports Binary Input Change Events when no specific variation requested		Reports time-tagged Binary Input Change Events when no specific variation requested	
<input type="checkbox"/>	Never	<input type="checkbox"/>	Never
<input checked="" type="checkbox"/>	Only time-tagged	<input checked="" type="checkbox"/>	Binary Input Change With Time
<input type="checkbox"/>	Only non-time-tagged	<input type="checkbox"/>	Binary Input Change With Relative Time
<input type="checkbox"/>	Configurable	<input type="checkbox"/>	Configurable (attach explanation)

Sends Unsolicited Responses		Sends Static Data in Unsolicited Responses:	
<input type="checkbox"/>	Never	<input checked="" type="checkbox"/>	Never
<input checked="" type="checkbox"/>	Configurable, See DNP configuration section	<input type="checkbox"/>	When Device Restarts
<input type="checkbox"/>	Only certain objects	<input type="checkbox"/>	When Status Flags Change
<input type="checkbox"/>	Sometimes (attach explanation)	No other options are permitted.	
<input checked="" type="checkbox"/>	ENABLE/DISABLE UNSOLICITED Function codes supported		
Default Counter Object/Variation		Counters Roll Over at:	
<input checked="" type="checkbox"/>	No Counters Reported	<input checked="" type="checkbox"/>	No Counters Reported
<input type="checkbox"/>	Configurable	<input type="checkbox"/>	Configurable (attach explanation)
<input type="checkbox"/>	Default Object: 20 and 21	<input type="checkbox"/>	16 Bits
<input type="checkbox"/>	Default Variation	<input type="checkbox"/>	32 Bits
<input type="checkbox"/>	Point-by-point list attached	<input type="checkbox"/>	Other Value: _____
<input type="checkbox"/>		<input type="checkbox"/>	Point-by-point list attached
Sends Multi-Fragment Responses			
<input checked="" type="checkbox"/>	Yes		
<input type="checkbox"/>	No		

Sequential File Transfer Support			
Append File Mode		Yes	✓ No
Custom Status Code Strings		Yes	✓ No
Permission Field		Yes	✓ No
File Events Assigned to Class		Yes	✓ No
File Events Poll Specifically		Yes	✓ No
File Events Send Immediately		Yes	✓ No
Multiple Blocks in a Fragment		Yes	✓ No
Max Number of Files Open	0		

Last modified: 23 October 2023

5.3. Implementation Table

The following table identifies the variations, function codes, and qualifiers supported by ATEvo Communications in both request messages and in response messages.

For some table entries, one of the following notes may apply:

Note 1: The Default variation refers to the variation in the response when the requested variation is '0' or in response to a class 0, 1, 2, or 3 request.

Note 2: For static (non-change-event) objects, qualifiers 17 or 28 are only responded when a specific request is sent with qualifiers 17 or 28, respectively. Otherwise, static object requests sent with qualifiers 00, 01, 06, 07, or 08, will be responded with qualifiers 00 or 01. For change event objects, qualifiers 17 or 28 are always responded except for object 70, which responds with qualifier 1B or 5B.

Note 3: For the ATEvo Communications Modules, a cold restart is implemented as a warm restart. The executable is not restarted, but the DNP process is restarted.

Note 4: Writes of Internal Indications are only supported for index 7 (Restart IIN1-7), and indices 16 and beyond (user-defined indications).

Implementation Table						
Color Key		Indicates Subset Level 3 Functionality (Beyond Level 2)		Indicates Functionality Beyond Subset Level 3		
Object			Request (Library Parse)		Response (Library will respond with)	
Object Number	Variation Number	Description	Function Codes (dec)	Qualifier Codes (hex)	Function Codes (dec)	Qualifier Codes (hex)
1	0	Binary Input (Variation 0 is used to request default variation)	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		
			22 (assign class)	07,08 (limited qty)		17,28 (index - see NOTE 2)
				17,28 (index)		
1	1 (default - see NOTE 1)	Binary Input	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		
			22 (assign class)	07,08 (limited qty)		17,28 (index - see NOTE 2)
				17,28 (index)		
1	2	Binary Input with Status	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		
			22 (assign class)	07,08 (limited qty)		17,28 (index - see NOTE 2)
				17,28 (index)		

2	0	Binary Input Change (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all)	129 (response)	17, 28 (index)
				07, 08 (limited qty)	130 (unsol. resp)	
2	1	Binary Input Changed without Time	1 (read)	06 (no range, or all)	129 (response)	17, 28 (index)
				07, 08 (limited qty)	130 (unsol. resp)	
2	2 (default - see NOTE 1)	Binary Input Change with Time	1 (read)	06 (no range, or all)	129 (response)	17, 28 (index)
				07, 08 (limited qty)	130 (unsol. resp)	
10	0	Binary Output Status (Variation 0 is used to request default variation)	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
10	2 (default - see NOTE 1)	Binary Output Status	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		

Implementation Table						
Color Key	Indicates Subset Level 3 Functionality (Beyond Level 2)			Indicates Functionality Beyond Subset Level 3		
Object			Request (Library Parse)		Response (Library will respond with)	
12	1	Control Relay Output Block	3 (select)	00,01 (start-stop)	129 (response)	echo of request
			4 (operate)	07,08 (limited qty)		
			5 (direct op)	17,28 (index)		
			6 (direct op, no ack)			
30	0	Analog Input (variation 0 is used to request default variation)	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
			22 (assign class)	06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
30	1	32-Bit Analog Input	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
			22 (assign class)	06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		

30	2 (default - see NOTE 1)	16-Bit Analog Input	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
			22 (assign class)	06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
30	3	32-Bit Analog Input without Flag	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
			22 (assign class)	06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
30	4	16-Bit Analog Input without Flag	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
			22 (assign class)	06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
32	0	Analog Change Event (variation 0 is used to request default variation)	1 (read)	06 (no range, or all)	129 (response)	17,28 (index)
				07,08 (limited qty)	130 (unsol. resp)	
32	1	32-bit Analog Change Event without Time	1 (read)	06 (no range, or all)	129 (response)	17,28 (index)
				07,08 (limited qty)	130 (unsol. resp)	

Implementation Table						
Color Key	Indicates Subset Level 3 Functionality (Beyond Level 2)			Indicates Functionality Beyond Subset Level 3		
Object		Request (Library Parse)		Response (Library will respond with)		
32	2 (default - see NOTE 1)	16-bit Analog Change Event without Time	1 (read)	06 (no range, or all)	129 (response)	17,28 (index)
				07,08 (limited qty)	130 (unsol. resp)	
32	3	32-bit Analog Change Event with Time	1 (read)	06 (no range, or all)	129 (response)	17,28 (index)
				07,08 (limited qty)	130 (unsol. resp)	
32	4	16-bit Analog Change Event with Time	1 (read)	06 (no range, or all)	129 (response)	17,28 (index)
				07,08 (limited qty)	130 (unsol. resp)	
34	0	Analog Input Reporting Deadband (variation 0 is used to request default variation)	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		

34	1 (default see NOTE 1)	16 bit Analog Input Reporting Deadband	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
34	2	16 bit Analog Input Reporting Deadband	2 (write)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
40	0	Analog Output Status (variation 0 is used to request default variation)	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
40	1	32-Bit Analog Output Status	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		

Implementation Table						
Color Key	Indicates Subset Level 3 Functionality (Beyond Level 2)			Indicates Functionality Beyond Subset Level 3		
Object			Request (Library Parse)		Response (Library will respond with)	
40	2 (default - see NOTE 1)	16-Bit Analog Output Status	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		
41	1	32-Bit Output Block	3 (select)	00,01 (start-stop)	129 (response)	echo of request
			4 (operate)	07,08 (limited qty)		
			5 (direct op)	17,28 (index)		
			6 (direct op, no ack)			
41	2	16-Bit Output Block	3 (select)	00,01 (start-stop)	129 (response)	echo of request
			4 (operate)	07,08 (limited qty)		
			5 (direct op)	17,28 (index)		
			6 (dir. op, no ack)			
50	0	Time and Date	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		17,28 (index - see NOTE 2)
				07,08 (limited qty)		
				17,28 (index)		

50	1 (default - see NOTE 1)	Time and Date	1 (read)	00,01 (start-stop)	129 (response)	00,01 (start-stop)
				06 (no range, or all)		
				07,08 (limited qty)		
				17,28 (index)		
			2 (write)	00,01 (start-stop)	129 (response)	
				06 (no range, or all)		
				07 (limited qty=1)		
				08 (limited qty)		
60	1	Class 0, Data	1 (read)	06 (no range, or all)	129 (response)	00,01 (start-stop)
			22 (assign class)			
60	2	Class 1 Data	1 (read)	06 (no range, or all)	129 (response)	17,28 (index - see NOTE 2)
				07,08 (limited qty)		
			20 (enbl. unsol.)	06 (no range, or all)		
			21 (dsbl. unsol.)			
			22 (assign class)			

Implementation Table						
Color Key	Indicates Subset Level 3 Functionality (Beyond Level 2)			Indicates Functionality Beyond Subset Level 3		
Object			Request (Library Parse)		Response (Library will respond with)	
60	3	Class 2 Data	1 (read)	06 (no range, or all)	129 (response)	17,28 (index - see NOTE 2)
				07,08 (limited qty)		
			20 (enbl. unsol.)	06 (no range, or all)		
			21 (dsbl. unsol.)			
22 (assign class)						
60	4	Class 3 Data	1 (read)	06 (no range, or all)	129 (response)	17,28 (index - see NOTE 2)
				07,08 (limited qty)		
			20 (enbl. unsol.)	06 (no range, or all)		
			21 (dsbl. unsol.)			
22 (assign class)						
No Object (function code only) - See Note 3			13 (Cold Restart)			
No Object (function code only)			14 (Warm Restart)			
No Object (function code only)			23 (Delay Meas.)			

5.4. DNP Point Lists

The tables found within each of the subsections listed below identify all the individual data points provided by this implementation of DNP3.

- [Binary Input Points](#)
- [Binary Output Points](#)
- [Analog Input Status Points](#)
- [Analog Output Status Points](#)
- [Internal Indication \(IIN\) Bits](#)

Last modified: 24 October 2023

5.4.1. Binary Input Points

The following table lists Binary Inputs (Object 1):

Binary Input Points			
Static (Steady-State) Object Number		1	
Change Event Object Number		2	
Request Function Codes supported:		1 (read)	
		22 (assign class)	
Static Variation reported when variation 0 requested:		1 (Binary Input without status)	
Change Event Variation reported when variation 0 requested:		2 (Binary Input Change with Time)	
Change Event Scan Rate:		5 seconds	
Point Index	Name/Description	If Point Status is Logic '1'	Initial Event Class
0	High Voltage DC (HVDC) Alarm	active	1
1	Low Voltage DC (LVDC) Alarm	active	1
2	DC Output Failure Alarm	active	1
3	AC input Failure Alarm	active	1
4	Positive Ground Fault Alarm	active	1
5	Negative Ground Fault Alarm	active	1
6	Common Alarm Relay (CAR) Alarm	active	1
7	High Voltage DC (HVDC) Shutdown	active	1
8	Low Voltage AC (LVAC) Shutdown	active	1
9	Forced Load Sharing Enabled	enabled	1
10	Temperature Compensation (TempCo) Enabled	enabled	1
11	Defective Temperature Probe	defective	1
12	Equalize Mode (0 = float)	equalize	1
13	(not used)	-	1
14	(not used)	-	1

15	Auto-Equalize Timer	enabled	1
16	HVDC Shutdown Enabled	enabled	1
17	(not used)	-	1
18	High Ripple Alarm	active	1
19	End of Discharge Alarm	active	1
20	Rectifier Over Temperature Alarm	active	1
21	DC Circuit Breaker Status	open	1
22	External Voltage Sense Fail Alarm	active	1
23	Internal Voltage Sense Fail Alarm	active	1
24	DC Power Supply Alarm	active	1
25	Open DC Output Alarm	active	1
26	High Level Detect Alarm	active	1
27	Low Level Detect Alarm	active	1
28	Low AC Supply Alarm	active	1
29	Current Limit Status	active	1
30	High Level Detect (HLD) Shutdown Status	active	1
31	Alarm Relay Failure	active	1
32	Rectifier Temperature Sense Failure	active	1
33	Display / US Processor Failure	active	1
34	Battery Open Alarm	active	1
35	Forced Load Sharing Communication Failure	active	1
36	Forced Load Sharing Independent Mode	active	1
37	Forced Load Sharing Not Ready	active	1
38	Battery Discharging	active	1
39	Battery Overtemp	active	1
40	Vgnd Imbalance Warning	active	1
41	Vgnd Imbalance Critical	active	1
42	Positive Ground Fault Warning	active	1
43	Negative Ground Fault Warning	active	1

44	Dynamic Current Limit	active	1
45	Power Board EEROM Failure	active	1
46	Main EEROM Failure	active	1
47	Hardware Level Detect Digital Potentiometer Failure	active	1
48	Ambient Temperature Probe Failure	active	1
49	Open AC Breaker	active	1
50	AC Meter Option Installed	active	1
51	AC Supply	active	1
52	Low Priority Alarm	active	1
53	High Priority Alarm	active	1
-	future	-	-

Last modified: 25 October 2023

5.4.2. Binary Output Points

The following table lists Binary Outputs (Object 10):

Binary Output Status Points			
Object Number Status		10	
Binary Output Status Points		1(read)	
Default Variation reported when variation 0 requested		2 (Binary Output Status)	
Control Relay Output Blocks			
Object Number		12	
Request Function Codes supported:		3 (select), 4 (operate)	
		5 (direct operate), 6 (direct operate, noack)	
Point Index	Name/Description	Latch 'OFF'	Latch 'ON'
0	Float / Equalize Mode	float	equalize
1	(not used)	-	-
2	(not used)	-	-
3	Manual Timer / Auto Equalize Timer	manual	auto
4	HVDC Shutdown	disable	enable
5	(not used)	-	-
6	Battery Temperature Compensation (TempCo) Enable	disable	enable
7	Battery Discharge Enable	disable	enable
8	Remote Voltage Sense Enable	disable	enable
9	Auto Run Battery Open Test Enable	disable	enable
10	Battery Open Test Ran	disable	enable
11	Dynamic Current Limit Enable	disable	enable
12	Battery Temperature Probe Enable	disable	enable
-	future	-	-

Last modified: 25 October 2023

5.4.3. Analog Input Status Points

The following table lists Analog Inputs (Object 30).

It is important to note that 16-bit and 32-bit variations of Analog Inputs, Analog Output Control Blocks, and Analog Output Statuses are transmitted through DNP as signed numbers. Even for analog input points that are not valid as negative values, the maximum positive representation is 32767.

The “Multiplier” column indicates the value by which each data point is multiplied. Since all data points are sent in integer format, floating point numbers are multiplied by a constant (1, 10, or 100) to maintain decimal information. For example, points with two decimal places of resolution are multiplied by 100 (5.67 is sent as 567) while points with one decimal place of resolution are multiplied by 10 (8.2 is sent as 82). To convert a data point to the correct value, simply divide the point by the “Multiplier” value.

The “Default Deadband” column is used to represent the absolute amount by which the point must change before an analog change event will be generated. The “Default Event Class” column is used to represent the class (1, 2, 3, or none) in which detected change events will be reported. Only the default values for these columns are shown here because the values may change in operation due to either local (user-interface) or remote (through DNP) configuration control.

Analog Input Status Points	
Static (Steady-State) Object Number	30
Change Event Object Number	32
Reporting Deadband Object Number	34
Request Function Codes supported:	1 (read)
	2 (write) - deadbands only
	22 (assign class)
Static Variation reported when variation 0 requested:	2 (16-bit Analog Input)
Change Event Variation reported when variation 0 requested:	2 (Analog Change Event without Time)
Reported Deadband Variation Reported when variation	1 (16-bit Reporting Deadband)

0 requested				
Change Event Scan Rate:		5 seconds		
Point Index	Name/Description	Multiplier (format)	Default Deadband	Default Event Class
0	Display / UI Processor Firmware Rev	1 (XXX.xxx.0)	1	2
1	DNP Firmware Rev	1 (XXX.xxx.0)	1	2
2	Main ATEvo Processor Firmware Rev	1 (XXX.xxx.0)	1	2
3	ATEvo Model Nominal Output Voltage Rating (Vdc)	1 (XXX)	1	2
4	ATEvo Model Nominal Output Current Rating (Adc)	1 (XXX)	1	2
5	Charger DC Output Voltage (Vdc)	10 (XXX.X)	1	2
6	Charger DC Output Current (Adc)	10 (XXX.X)	1	2
7	Equalize Time Remaining (minutes)	1 (XXXX)	1	2
8	(not used)	1 (XXXXX)	1	2
9	Battery Temperature (°C)	10 (XXX.X)	1	2
10	Rectifier Temperature (°C)	10 (XXX.X)	1	2
11	Vgnd Imbalance Lean (1 - pos(+)> 5%, 2 - neg(-)> 5%, 0 - less than 5%)	1 (X)	1	2
12	Positive Terminal to Ground	1 (XXXXX)	1	2
13	Negative Terminal to Ground	1 (XXXXX)	1	2
14	Vgnd Imbalance (Vdc)	10 (XXX.X)	1	2
15	Resistance to Ground (kOhms) (1 - pos(+) to gnd, 2 - neg(-) to gnd, 0 - invalid)	1 (X)	1	2
16	Loadshare Enabled (1 - primary, 2 - secondary, 0 - not enabled)	1 (X)	1	2
17	Battery Open Test Timestamp Low (seconds since January 1, 2000)	1 (XXXXX)	1	2

18	Battery Open Test Timestamp High (seconds since January 1, 2000)	1 (XXXXX)	1	2
19	Ambient Temperature (°C)	10 (XXX.X)	1	2
20	Heartbeat	1 (XXXXX)	1	2
21	AC Input Voltage - Phase A (Vac)	10 (XXXX.X)	1	2
22	AC Input Voltage - Phase B (Vac)	10 (XXXX.X)	1	2
23	AC Input Voltage - Phase C (Vac)	10 (XXXX.X)	1	2
24	AC Input Current - Phase A (Aac)	10 (XXXX.X)	1	2
25	AC Input Current - Phase B (Aac)	10 (XXXX.X)	1	2
26	AC Input Current - Phase C (Aac)	10 (XXXX.X)	1	2
27	AC Line Frequency (Hz)	100 (XXX.XX)	1	2
28	Battery Current (Adc)	10 (XXXX.X)	1	2
-	future	-	-	-

 Firmware revision format (XXX.xxx.0) represents Major Version.Minor Version.0

- Upper 8 bits of register value are the Major Version
- Lower 8 bits of register value are the Minor Version
- Example: Version 10.6.0 would be 0x0A06 (hex) = 2566 (decimal)

Last modified: 25 October 2023

5.4.4. Analog Output Status Points

The following table lists Analog Outputs (Object 40).

The valid range for many of these points depends on ATevo battery charger model (Vdc - Adc rating). To determine valid ranges of these set points, refer to user supplement ([JA5124-02](#)). It is important to note that 16-bit and 32-bit variations of Analog Inputs, Analog Output Control Blocks, and Analog Output Statuses are transmitted through DNP as signed numbers. Even for analog input points that are not valid as negative values, the maximum positive representation is 32767.

The “Multiplier” column indicates the value by which each data point is multiplied. Since all data points are sent in integer format, floating point numbers are multiplied by a constant (1, 10, or 100) to maintain decimal information. For example, points with two decimal places of resolution are multiplied by 100 (5.67 is sent as 567) while points with one decimal place of resolution are multiplied by 10 (8.2 is sent as 82). To convert a data point to the correct value, simply divide the point by the “Multiplier” value.

When writing a value to the Analog Output, you must multiply the desired value by the constant in the ‘Multiplier’. For example, if you want to change the ‘Float Voltage Set Point’ to 132 volts, you need to write 1320 to Analog Output ‘0’ ($132 \times 10 = 1320$); ‘10’ is the multiplier for Analog Output Point ‘0’.

The ‘Valid Range’ column lists the possible values that can be successfully written to the associated Analog Output point. This is the true value, and does not include the multiplier correction. Attempting to write values outside of this range will result in a DNP3 error response.

Analog Output Status Points			
Object Number Status		40	
Request Function Codes Supported		1(read)	
Default Variation reported when variation 0 requested		2 (16-bit Analog Input)	
Analog Output Blocks			
Object Number		41	
Request Function Codes supported:		3 (select), 4 (operate)	
		5 (direct operate), 6 (direct operate, noack)	
Point Index	Name/Description	Multiplier (format)	Valid Range

0	Float Voltage Set Point (Vdc)	10 (XXX.X)	see JA5124-02
1	Equalize Voltage Set Point (Vdc)	10 (XXX.X)	see JA5124-02
2	Equalize Timer Set Point (hours)	1 (XX)	1 <= XX <= 99
3	Current Limit Set Point (Adc)	10 (XXX.X)	see JA5124-02
4	High Voltage DC Alarm Set Point (Vdc)	10 (XXX.X)	see JA5124-02
5	Low Voltage DC Alarm Set Point (Vdc)	10 (XXX.X)	see JA5124-02
6	High Level Detect Set Point (Vdc)	10 (XXX.X)	see JA5124-02
7	Low Level Detect Set Point (Vdc)	10 (XXX.X)	see JA5124-02
8	End of Discharge Set Point (Vdc)	10 (XXX.X)	see JA5124-02
9	AC Ripple Alarm Set Point (mV)	1 (XXX)	50 < XXX < 250 (in 5mV steps)
10	Positive Ground Fault Set Point (kOhms)	1 (XX)	10K <= XX <= 40K (in 1 kOhm steps)
11	Negative Ground Fault Set Point (kOhms)	1 (XX)	10K <= XX <= 40K (in 1kOhm steps)
12	Battery Type (chemistry)	1 (X)	0 - lead acid, 1 - NiCd
13	Charger Mode Setting	1 (X)	0 - shutdown, 1 - battery open test, 2 - float, 3 - timed equalize
14	Ground Fault Critical Setpoint (kOhms)	1 (XX)	1 <= X <= 50
15	Vgnd Imbalance Warning Setpoint (Vdc)	1 (XX)	see JA5124-02
16	Vgnd Imbalance Critical Setpoint (Vdc)	1 (XX)	see JA5124-02
17	Battery Overtemp Setpoint (°C)	10 (XX.X)	30 <= XX <= 60
18	Battery Open Test	1 (XXX)	1 <= X <= 180

	Frequency (days)		
19	Battery Open Test Duration (minutes)	1 (X)	$1 \leq X \leq 8$
20	Battery Open Test Setpoint (Vdc)	1 (XXX)	see JA5124-02
21	Date/Time Low (seconds since January 1, 2000)	1 (XXXXXX)	lower 16-bits
22	Date/Time High (seconds since January 1, 2000)	1 (XXXXXX)	upper 16-bits
-	future	-	-

Last modified: 25 October 2023

5.4.5. Internal Indication (IIN) Bits

The following Internal Indication bits are defined by the DNP3 protocol.

Internal Indication Bits		
Object Number		80
Request Function Codes supported:		1 (read), 2 (write)
Default Variation reported when variation 0 requested		
Point Index	Description and Conditions	Writeable?
0	IIN1-0 All Stations - set after a broadcast message (any message 0 using a destination address of 0xffff0 or above) has been received. Does not indicate an error condition.	No
1	IIN1-1 Class 1 event data available. Can be set at any time and does not indicate an error condition.	No
2	IIN1-2 Class 2 event data available. Can be set at any time and does not indicate an error condition.	No
3	IIN1-3 Class 3 event data available. Can be set at any time and does not indicate an error condition.	No
4	IIN1-4 Time synchronization required. Can be set at any time and does not indicate an error condition.	No
5	IIN1-5 Local mode. Set if some points are uncontrollable via DNP.	No
6	IIN1-6 Device Trouble.	No
7	IIN1-7 Device restart. Set only under specific conditions. Does not indicate an error condition.	Yes
8	IIN2-0 Function Unknown. Generally means that the function code (octet 2 of the request header) cannot be processed.	No
9	IIN2-1 Object Unknown. Generally means that the function code could be processed but the object group / variation could not be processed.	No
10	IIN2-2 Parameter Error. Generally indicates that both the function 10 code and object group / variation could be processed but that the qualifier / range field is in error.	No
11	IIN2-3 Buffer Overflow. Indicates that an event buffer has overflowed, and that change events, of at least one type, have been lost.	No

12	IIN2-4 Already Executing.	No
13	IIN2-5 Bad configuration.	No
14	IIN2-6 Reserved. Always 0.	No
15	IIN2-7 Reserved. Always 0.	No
-	future	-

Last modified: 25 October 2023

6. Modbus

SECTION TOPICS
Introduction to Modbus
Supported Function Codes
Modbus Binary Outputs
Binary Inputs
Modbus Input Registers
Modbus Holding Registers

Last modified: 25 October 2023

6.1. Introduction to Modbus

This section provides specifics for implementing Modbus protocol via the ATevo Communications Adapters.

The Modbus protocol was implemented using the Modicon Modbus Protocol Reference Guide PI-MBUS-300 Rev. J.

Last modified: 25 October 2023

6.2. Supported Function Codes

The following standard Modbus function codes are supported:

- 01 - Read Coil Status
- 02 - Read Input Status
- 03 - Read Holding Registers
- 04 - Read Input Registers
- 05 - Read Single Coil
- 06 - Preset Single Register
- 15 - Force Multiple Coils
- 16 - Preset Multiple Registers

Last modified: 25 October 2023

6.3. Modbus Binary Outputs (Coils)

The following table lists the Binary Output registers:

Modbus Binary Outputs			
Address	Name/Description	Status 'OFF' (Logic '0')	Status 'ON' (Logic '1')
00001	Float / Equalize Mode	float	equalize
00002	(not used)	-	-
00003	(not used)	-	-
00004	Manual Timer / Auto Equalize Timer	manual	auto
00005	HVDC Shutdown	disable	enable
00006	(not used)	-	-
00007	Battery Temperature Compensation	disable	enable
00008	Battery Discharge	disable	enable
00009	Remote Sense	disable	enable
00010	Auto Run Battery Open Test	disable	enable
00011	Battery Open Test Ran	disable	enable
00012	Dynamic Current Limit	disable	enable
00013	Battery Temperature Probe	disable	enable
-	future	-	-

Last modified: 25 October 2023

6.4. Binary Inputs

The following table lists the Binary Input Status registers:

Modbus Binary Input Status Registers		
Address	Name/Description	If Status is 'ON' (Logic '1')
10001	High Voltage DC (HVDC) Alarm	active
10002	Low Voltage DC (LVDC) Alarm	active
10003	DC Output Failure Alarm	active
10004	AC input Failure Alarm	active
10005	Positive Ground Fault Alarm	active
10006	Negative Ground Fault Alarm	active
10007	Common Alarm Relay (CAR) Alarm	active
10008	High Voltage DC (HVDC) Shutdown Active	active
10009	Low Voltage AC (LVAC) Shutdown	active
10010	Forced Load Sharing Enabled	enabled
10011	Temperate Compensation (TempCo) Enabled	enabled
10012	Defective Temperate Probe	defective
10013	Equalize Mode (0 = float)	equalize
10014	(not used)	-
10015	(not used)	-
10016	Auto-Equalize Timer	enabled
10017	HVDC Shutdown Enabled	enabled
10018	(not used)	-
10019	High Ripple Alarm	active
10020	End of Discharge Alarm	active
10021	Rectifier Over Temperature Alarm	active
10022	DC Breaker Status	open
10023	External Voltage Sense Fail Alarm	active
10024	Internal Voltage Sense Fail Alarm	active

10025	DC Power Supply Alarm	active
10026	Open DC Output Alarm	active
10027	High Level Detect Alarm	active
10028	Low Level Detect Alarm	active
10029	Low AC Shutdown Alarm	active
10030	Current Limit Status	active
10031	High Level Detect Shutdown Status	active
10032	Alarm Relay Failure	active
10033	Rectifier Temperature Sense Failure	active
10034	Display / UI Processor Failure	active
10035	Battery Open Alarm	active
10036	Loadshare Communication Failure	active
10037	Loadshare Independent Mode	active
10038	Loadshare Not Ready	active
10039	Battery Discharging	discharging
10040	Battery Overtemp	=> setpoint
10041	Vgnd Imbalance Warning	=> setpoint
10042	Vgnd Imbalance Critical	=> setpoint
10043	Positive Ground Fault Warning	res to gnd <= setpoint
10044	Negative Ground Fault Warning	res to gnd <= setpoint
10045	Dynamic Current Limit	active
10046	Power Board EEROM Failure	failed
10047	Main EEROM Failure	failed
10048	Hardware Level Detect Digital Potentiometer Failure	potentiometer failed
10049	Ambient Temperature Probe Failure	probe failed
10050	Open AC Breaker	tripped
10051	AC Meter Option Installed	installed
10052	AC Supply (1PH or 3PH)	three phase
10053	Low Priority Alarm	active

10054	High Priority Alarm	active
-	future	-

Last modified: 25 October 2023

6.5. Modbus Input Registers

The following table lists the Modbus Input Registers.

For each point, the “Multiplier” column indicates the value by which the register data are multiplied. Since all data are sent in integer format, floating point numbers are multiplied by a constant (1, 10, or 100) to maintain decimal information. For example, registers with two decimal places of resolution are multiplied by 100 (5.67 is sent as 567) while registers with one decimal place of resolution are multiplied by 10 (8.2 is sent as 82). To convert a register to the correct value, simply divide the register value by the “Multiplier” value.

Modbus Binary Input Status Registers		
Address	Name/Description	Multiplier (format)
30001	Display Processor Firmware Rev	1 (XXX.xxx.0)
30002	Modbus Firmware Rev	1 (XXX.xxx.0)
30003	Main Processor Firmware Rev	1 (XXX.xxx.0)
30004	Model Nominal Output Voltage Rating (Vdc)	1 (XXX)
30005	Model Nominal Output Current Rating (Adc)	1 (XXX)
30006	Charger DC Output Voltage (Volts)	10 (XXX.X)
30007	Charger DC Output Current (Amperes)	10 (XXX.X)
30008	Equalize Time Remaining (minutes)	1 (XXXX)
30009	(not used)	1 (XXXXX)
30010	Battery Temperature (°C)	10 (XXX.X)
30011	Rectifier Temperature (°C)	10 (XXX.X)
30012	Vgnd Imbalance Lean (1 - pos(+) > 5%, 2 - neg(-) > 5%, 0 - less than 5%)	1 (X)
30013	Positive Terminal to Ground	1 (XXXXX)
30014	Negative Terminal to Ground	1 (XXXXX)
30015	Vgnd Imbalance (Vdc)	10 (XXX.X)
30016	Resistance to Ground (kOhms) (1 - pos(+) to gnd, 2 - neg(-) to gnd, 0 - invalid)	1 (X)
30017	Loadshare Enabled (1 - primary, 2 - secondary, 0 - not enabled)	1 (X)

30018	Battery Open Test Timestamp Low (seconds since January 1, 2000)	1 (XXXXX)
30019	Battery Open Test Timestamp High (seconds since January 1, 2000)	1 (XXXXX)
30020	Ambient Temperature	10 (XXX.X)
30021	Heartbeat	1 (XXXXX)
30022	AC Input Voltage Phase A	10 (XXXX.X)
30023	AC Input Voltage Phase B	10 (XXXX.X)
30024	AC Input Voltage Phase C	10 (XXXX.X)
30025	AC Input Current Phase A	10 (XXXX.X)
30026	AC Input Current Phase B	10 (XXXX.X)
30027	AC Input Current Phase C	10 (XXXX.X)
30028	AC Line Frequency	100 (XXX.XX)
30029	Battery Current	10 (XXXX.X)
-	future	-

 Firmware revision format (XXX.xxx.0) represents Major Version.Minor Version.0

- Upper 8 bits of register value are the Major Version
- Lower 8 bits of register value are the Minor Version
- Example: Version 10.6.0 would be 0x0A06 (hex) = 2566 (decimal)

Last modified: 25 October 2023

6.6. Modbus Holding Registers

The following table lists the Modbus Holding Registers.

For each point, the “Multiplier” column indicates the value by which the register data are multiplied. Since all data are sent in integer format, floating point numbers are multiplied by a constant (1, 10, or 100) to maintain decimal information. For example, registers with two decimal places of resolution are multiplied by 100 (5.67 is sent as 567) while registers with one decimal place of resolution are multiplied by 10 (8.2 is sent as 82). To convert a register to the correct value, simply divide the register value by the “Multiplier” value.

When writing a value to a Holding Register, you must multiply the desired value by the constant in the “Multiplier”. For example, to change the “Float Voltage Set Point” to 132 volts, you would need to write 1320 to Holding Register “40001” ($132 \times 10 = 1320$). The “10” is the multiplier constant listed in “Multiplier” column for Holding Register “40001”.

The “Valid Range” column lists the possible values that can be successfully written to the associated Holding Register. This is the true value and does not include the multiplier correction. Attempting to write values outside of this range will result in a Modbus error returned as an Exception Response.

The valid range for many of these points depends on ATevo battery charger model (Vdc - Adc rating). To determine valid ranges of these set points, refer to user supplement ([JA5124-02](#)).

Modbus Holding Registers			
Address	Name/Description	Multiplier (format)	Valid Range
40001	Float Voltage Set Point (Vdc)	10 (XXX.X)	see JA5124-02
40002	Equalize Voltage Set Point (Vdc)	10 (XXX.X)	see JA5124-02
40003	Equalize Timer Set Point (hours)	1 (XX)	$1 \leq XX \leq 99$
40004	Current Limit Set Point (Adc)	10 (XXX.X)	see JA5124-02
40005	High Voltage DC Alarm Set Point (Vdc)	10 (XXX.X)	see JA5124-02
40006	Low Voltage DC Alarm Set Point (Vdc)	10 (XXX.X)	see JA5124-02
40007	High Level Detect Set Point (Vdc)	10 (XXX.X)	see JA5124-02

40008	Low Level Detect Set Point (Vdc)	10 (XXX.X)	see JA5124-02
40009	End of Discharge Set Point (Vdc)	10 (XXX.X)	see JA5124-02
40010	AC Ripple Alarm Set Point (mV)	1 (XXX)	50 < XXX < 250 (in 5mV steps)
40011	Positive Ground Fault Set Point (kOhms)	1 (XX)	10K <= XX <= 40K (in 1 kOhm steps)
40012	Negative Ground Fault Set Point (kOhms)	1 (XX)	10K <= XX <= 40K (in 1kOhm steps)
40013	Battery Type (chemistry)	1 (X)	0 - lead acid, 1 - NiCd
40014	Charger Mode Setting	1 (X)	0 - shutdown, 1 - battery open test, 2 - float, 3 - timed equalize
40015	Ground Fault Critical Setpoint (kOhms)	1 (XX)	1 <= X <= 50
40016	Vgnd Imbalance Warning Setpoint (Vdc)	1 (XX)	see JA5124-02
40017	Vgnd Imbalance Critical Setpoint (Vdc)	1 (XX)	see JA5124-02
40018	Battery Overtemp Setpoint (°C)	10 (XX.X)	30 <= XX <= 60
40019	Battery Open Test Frequency (days)	1 (XXX)	1 <= X <= 180
40020	Battery Open Test Duration (minutes)	1 (X)	1 <= X <= 8
40021	Battery Open Test Setpoint (Vdc)	1 (XXX)	see JA5124-02
40022	Date/Time Low (seconds since January 1, 2000)	1 (XXXXXX)	lower 16-bits
40023	Date/Time High (seconds since January 1, 2000)	1 (XXXXXX)	upper 16-bits
-	future	-	-

7. Appendix – Document Control Information

Revision Numbers: Document and Page

Document revisions are controlled by the application which was used to produce this online manual which is found at <https://www.manula.com>. The revision number for this site is displayed in the header for all pages.

Each page of the manual may be revised by the manufacturer on a regular basis in order to provide customers updated information in a timely manner. The revision date of each page is shown in the footer of each page.

Parts Data Package

A job-specific customized Parts Data Package report is supplied with every shipped ATevo battery charger. The data listed in this report supercedes any information featured in product literature, standard documentation, and/or quote documents. The parts and quantities listed are applicable only to the battery charger featuring the same serial number listed on the Parts Data Package report.

Drawings

A customized record drawing package is available for any ATevo, featuring a unit-specific drawing list / data nameplate detail, outline drawing, itemized internal component layout, electrical schematic with component ratings, and a full connection diagram. If the standard drawings featured in this manual are not sufficient, please contact your sales representative for drawing availability from the battery charger manufacturer.

Any job-specific custom drawings supplied with an ATevo supercede the standard drawings featured in the manual. The standard drawings featured in the manual may not be included with custom printed manuals, when job-specific custom drawings are supplied.

Online Availability of Related Information

Other related product operating manuals, feature and accessory special instructions, standard drawings (including the ones listed in this manual), field service instructions, and product application notes for the AT Series microprocessor- controlled battery chargers and battery charger products are available online at <http://www.ATSeries.net/>. Saved in Adobe Acrobat Portable Document Format (PDF), they are readily available for downloading and printing.

If revision levels differ between the drawings embedded in this manual and the full online PDF drawings, refer to document with the higher revision level. For document availability of private-

labeled manuals and/or standard drawings, please contact your sales representative.

Last modified: 25 October 2023

8. SAFETY

! SAFETY INSTRUCTIONS - PLEASE READ AND FOLLOW TO AVOID SERIOUS INJURY OR DEATH

SYMBOL	MEANING
	Imminently hazardous situation, which if not avoided, WILL result in death or serious injury.
	Potentially hazardous situation, which if not avoided, could result in death or serious injury.
	Potentially hazardous situation, which if not avoided, could result in minor or moderate injury (e.g. minor burns, bruising from pinch points, minor chemical irritation). May also be used to alert against unsafe practices.
	Important information not related to personal injury (e.g. messages related to equipment or property damage).

Safety warnings below apply only when working with the communications features of the ATevo. When performing any other operation or service task, it is necessary to reference the full set of safety instructions in the ATevo Operations Manual.

SYMBOL	INSTRUCTION
	Do not touch any uninsulated parts, especially the input and output connections, as there is the possibility of electrical shock.
	Remove all jewelry (watches, rings, etc.) before proceeding with installation or servicing to avoid electrical shock hazards.
	Use a ground strap while installing these sensitive components.

Last modified: 23 October 2023