NVMesh Operator Installation Guide

2.4 — Last update: 18 November 2021 Excelero, Ltd.

Table of Contents

1.	Copyright and Trademark Information	2
2.	Introduction	3
3.	NVMesh OpenShift Operator Installation	4
	3.1. YAML Installation	5
	3.2. Setting up Repository Access	6
	3.3. Operator Installation	7
	3.4. Remove the Default Storage Class	9
	3.5. Create an NFS Server Instance	10
	3.6. Add a PV to the Cluster	19
	3.7. Install NVMesh Pods	21
	3.8. Expose Management Routes	25
4.	Creating PVCs with NVMesh Storage	26
	4.1. Format Drives	27
	4.2. Create PersistentVolumeClaims	28
5.	NVMesh OpenShift Operator on Azure	29
	5.1. Prerequisites	30
	5.1.1. Resource Limits	31
	5.1.2. Roles and Permissions	37
	5.1.3. Public DNS Zone	38
	5.1.4. Azure CLI	39
	5.2. OpenShift Cluster on Azure	40
	5.2.1. Deploying the Cluster	41
	5.2.2. Accessing the Cluster	47
	5.2.3. Infiniband Only	48
6.	NVMesh on Azure Kubernetes Service	56
	6.1. Quick Summary	57
	6.2. Deploying the AKS Cluster	59
	6.2.1. Login via the Azure CLI	61
	6.2.2. Verify Azure Subscription Access	62
	6.2.3. Create a Resource Group	63
	6.2.4. Create the Cluster	64
	6.3. Deploying NVMesh on AKS	65
	6.3.1. Set up Repository Access	66
	6.3.2. Deploy Node Pool for Targets	67
	6.3.3. Get the NVMesh Operator	69
	6.3.4. Deploy the NVMesh Operator	70
	6.3.5. Deploy NVMesh Pods	71

6.3.6. Create PVCs (Persistent Volume Claims)	. 72
6.4. Performance Tuning	74

1. Copyright and Trademark Information

© 2015-2021 Excelero, Inc. All rights reserved. Specifications are subject to change without notice. Excelero, the Excelero logo, MeshProtect, and Remote-Direct-Drive-Access (RDDA) are trademarks of Excelero, Inc. in the United States and/or other countries. NVMesh® is a registered trademark of Excelero, Inc. in the United States.

Mellanox and ConnectX are registered trademarks of NVIDIA.

Intel is a registered trademark of Intel Corporation. Xeon and Core are trademarks of Intel Corporation. All other brands or products are trademarks or registered trademarks of their respective holders and should be treated as such.

Red Hat, Red Hat Enterprise Linux, the Red Hat logo and OpenShift are trademarks of Red Hat, Inc., registered in the United States and other countries.

Linux® is the registered trademark of Linus Torvalds in the United States and other countries.

XFS® is a trademark of Silicon Graphics International Corp. or its subsidiaries in the United States and/or other countries.

Ubuntu® is a trademark of Canonical or its subsidiaries in the United States and/or other countries. Node.js® is an official trademark of Joyent. NVMesh is not formally related to or endorsed by the official Joyent Node.js open source or commercial project

OpenStack® is an official trademark of the OpenStack Foundation.

MONGO and MONGODB are trademarks of MongoDB Inc., registered in the United States and other countries.

Microsoft® and Azure® are trademarks of Microsoft, Inc., registered in the United States and other countries.

2. Introduction

The purpose of this guide is to provide simple instructions for installing and using the *NVMesh* operator in an OpenShift environment.

Basic knowledge of OpenShift administration is recommended.

3. NVMesh OpenShift Operator Installation

In this part we will describe the full procedure for installing NVMesh operator and running NVMesh on the OpenShift cluster

3.1. YAML Installation

Installing YAMLs is a common procedure when working with OpenShift.

To install a component to an OpenShift cluster, use the following procedure.

First, click + at the top right of the UI



On the Import page, select project "default" from the dropdown at the top. Paste the YAML in the text box and click "Create"

1			? View sh

3.2. Setting up Repository Access

To access the *NVMesh* repository, import access credentials.

- 1. Obtain YAMLs containing the required secrets for repository access from <u>sales@excelero.com</u>.
- 2. Import the secrets YAMLs, see Installing YAMLs.

There are two secret YAMLs.

- The first provides access to Excelero's docker registry
- The second provides access to Excelero's RPM repositories

3.3. Operator Installation

Go to the OperatorHub page and search for *NVMesh*.

Red Hat OpenShift Container F	Platform					₩ \$ 1 © Ø	kube:admin v
	Ŧ	Project: openshift-marketplace	•	You are logged in as a temporary administrat	NVMest	Operator	×
	~	OperatorHub Discover Operators from the Kuberr		rtners, curated by Red Hat. You can purchase	Install		
		services to your developers. After in	stallation, the Operator capabiliti	ies will appear in the Developer Catalog prov	Latest version 0.7.0-42	Excelero NV/Mesh is a low-latency distributed block storage solution providing web-scale access to hot data in any cloud, private or public. NV/Mesh enables pooling and sharing N network. It drives both local and distributed file systems. The solution features an intellior	applications VMe across any ent management
		Al/Machine Learning Application Runtime	Nymesh		Capability level Basic Install Seamless Upgrades	layer that abstracts underlying hardware with CPU offload, creates logical volumes with re provides centralized, intelligent management and monitoring. Applications can enjoy the throughput and IO/s of local NVMe devices with the convenience of centralized storage v considered by the local intervention of the convenience of centralized storage v	edundancy and latency, while avoiding
Operators OperatorHub	Ť	Big Data Cloud Provider Database	Ŧ	Æ	 Full Lifecycle Deep Insights Auto Pilot 	proprietary nationale toocs in and reducing the overall scorage FCC in public cloud environ NVMesh supports instances, both virtualized and containerized, that feature NVMe drives instances with local NVMe drives have become widely available allowing easy transition b premises and public cloud deployments of NVMesh.	s. Public cloud etween on-
Installed Operators		Developer Tools Integration & Delivery	NVMesh Operator provided by Excelero	NVMesh Operator provided by Excelero	Provider type NVMesh Catalog Source	Excelero NVMesh has a flexible distributed data protection architecture providing multipl schemes that can be tuned for specific use cases and data center restrictions and require aneura naibalities and to radiuse net. The sectors can also used around failure to trivia for	e redundancy ements to

Install the operator in the default namespace.

OperatorHub > Operator Installation Install Operator	
Install your Operator by subscribing to one of the update channels to keep the Operator up to date.	The strategy determines either manual or automatic updates.
Update channel *	NVMesh Operator
leta	provided by Excelero Provided APIs
Installation mode • All namespaces on the cluster (default) Operator will be available in all Namespaces.	NVM NVMesh
 A specific namespace on the cluster Operator will be available in a single Namespace only. 	Represents an inviniesh Cluster
Installed Namespace *	•
Approval strategy *	
 Automatic Manual 	
Install	

Upon installation completion, the following page should appear.



3.4. Remove the Default Storage Class

By default, Mongo PVCs will be created with a default storage class, which means they will be bound only to PVs created from this storage class. In order to bypass this, we will unset the default storage class. Go to *Storage* and then *StorageClasses* using the left menu, click options for *managed-premium* storage class and click *Edit annotations* from the drop-down menu at the right.

Workloads 🗸	^	You are logged in as a temporary administrative user. Update the	cluster OAuth configuration to allow others to log in.	
Pods	Storage Classes			Croate Storage Class
Deployments				Create Otorage Class
DeploymentConfigs	Name Vame Search by name			
StatefulSets	Name 1	Provisioner 1	Reclaim Policy 💲	
Secrets	SC managed-premium – Default	kubernetes.io/azure-disk	Delete	
ConfigMaps				
Crop John	1			Edit labels
lohe				Edit annotations
DoomonSote				Edit StorageClass
DepliceSate				Delete StorageClass
Replication Controllors				
HerizontalDedAutoscalara				
HonzontaiPodAutoscalers				
Networking >				
Storage ¥				
Storage				
PersistentVolumes				
PersistentVolumeClaims				
StorageClasses				
VolumeSnapshots				
VolumeSnapshotClasses				
VolumeSnapshotContents				

Remove the only key defined by using the minus button and click Save.

KEY	VALUE	
storageclass.kubernetes.io/is-	· true	0
• • • •		
Add more		

3.5. Create an NFS Server Instance

All **NVMesh Management Servers** should have access to two shared volumes: one for Mongo and one for backups. This can be done by Azure files, NFS server, or any other persistent volume method.

The following uses the NFS method. To use another method or if an NFS server is already set, skip to <u>Add a</u> <u>Persistent Volume to the Cluster</u> stage.

Create an NFS Server Instance

Go to <u>Microsoft Azure – Resource Groups</u> and choose the resource group associated with the cluster (it should have a name starting with the cluster name). Click *Add*.

Search (Ctrl+/)	« 🕂 Add ≡≡ Edit columns 📋 Delete resource group 🖒 Refresh 🞍 Export to CSV 😚 Ope	n query 💛 Feedback 🔋 Open in mobile	\oslash Assign tags \rightarrow Move \checkmark \textcircled{II} Delete \cdot	
Overview	Essentials			JSON
Activity log	Subscription (change) : Excelero 20210123	Deployments : No deployments		
Access control (IAM)	Subscription ID : 2ffe1cec-eb7b-496c-9628-81e629fe435b	Location : West Europe		
Tags	Tags (change) : kubernetes.io_cluster.yoavopen-6jsb4 : owned			
Events	Filter for any field Type == all X Location == all X ^t Add filter			
ings	Showing 1 to 26 of 26 records. Show hidden types ①		No grouping V List vi	ew
Deployments		Time Al	Leasting &	
Security		Type 1.		
Policies	□ □ □ clusterqx5qf	Storage account	West Europe	
Properties	imageregistryyoavop8c5ph	Storage account	West Europe	
Locks	yoavopen-6jsb4	Image	West Europe	
Management	yoavopen-6jsb4	Load balancer	West Europe	
Cast analysis	yoavopen-6jsb4-a20536fcb48be4275833e3cabd8c9a2c	Public IP address	West Europe	
Cost analysis	🗌 😤 yoavopen-6jsb4-identity	Managed Identity	West Europe	
Cost alerts (preview)	🗌 💠 yoavopen-6jsb4-internal	Load balancer	West Europe	
Budgets	🔲 🖳 voavopen-6jsb4-master-0	Virtual machine	West Europe	
Advisor recommendations	Source State	Disk	West Europe	
itoring	🔲 晃 yoavopen-6jsb4-master-1	Virtual machine	West Europe	
Insights (preview)	Solution States	Disk	West Europe	
Alerts	yoavopen-6jsb4-master-2	Virtual machine	West Europe	
Metrics	Source State	Disk	West Europe	
Diagnostic settings	🗌 🥵 yoavopen-6jsb4-master0-nic	Network interface	West Europe	
Logs	🗌 🤹 yoavopen-6jsb4-master1-nic	Network interface	West Europe	
Advisor recommendations	🗌 🌇 yoavopen-6jsb4-master2-nic	Network interface	West Europe	
Workbooks	voavopen-fijsb4-nsg	Network security group	West Europe	

On the left, click Compute and then choose Virtual Machine.



Edit the virtual machine settings as follows:

- Virtual Machine name: NFS
- Region: same as the cluster
- Image: Ubuntu Server 18.04

- Size: a minimal machine should be sufficient, for instance "Standard B1Is (1 vcpu, 0.5 GiB memory)"
- Administrator account: it is easiest to use SSH and paste an existing public key

Create a virtual mac	hine
Subscription * ①	Excelero 20210123
Resource group * ()	yoavopen-6jsb4-rg
Instance details	
Virtual machine name * ①	NFS
Region * ①	(Europe) West Europe
Availability options	No infrastructure redundancy required
Image * 🛈	Ubuntu Server 18.04 LTS - Gen1 V
Azure Spot instance ①	
Size * ①	Standard_B1Is - 1 vcpu, 0.5 GiB memory (\$4.38/month)
Administrator account	
Authentication type	 SSH public key Password
	Azure now automatically generates an SSH key pair for you and allows you to store it for future use. It is a fast, simple, and secure way to connect to your virtual machine.
Username * ①	yoav 🗸
SSH public key source	Use existing public key
SSH public key * ①	
	I Learn more about creating and using SSH keys in Azure ⊡ [*]
Inbound port rules	
Select which virtual machine network network access on the Networking ta	c ports are accessible from the public internet. You can specify more limited or granular ab.
Public inbound ports * ①	O None
	 Allow selected ports

SSH (22)

Next : Disks >

< Previous

A This will allow all IP addresses to access your virtual machine. This is only recommended for testing. Use the Advanced controls in the Networking tab

to create rules to limit inbound traffic to known IP addresses.

Review + create

Select inbound ports *

 \sim

Click *Next* and then *disks*.

Click *Next* and then *networking*.

Choose the worker subnet as the subnet on this machine will run the managements pods, and use a public IP (don't touch the field).

Create	a vi	rtual mac	hine				
Basics D	Disks	Networking	Management	Advanced	Tags	Review + create	
Define netw ports, inbou Learn more	vork cor und and ⊡	nnectivity for your l outbound conne	r virtual machine b ectivity with securit	y configuring r y group rules, o	network int or place be	erface card (NIC) settings hind an existing load bal	. You can control ancing solution.
Network in	nterfac	e					
When creati	ing a vi	rtual machine, a r	network interface w	vill be created f	for you.		
Virtual netw	ork *	0	yoavoper Create nev	n-6jsb4-vnet			
Subnet * 🤅	D		yoavoper Manage su	n-6jsb4-worker Ibnet configura	-subnet (1 ation	0.0.32.0/19)	
Public IP ①)		(new) NF	S-ip			
NIC network	k securi	ty group 🕕	Create nev None Basic Advar	nced			
			i The asso mar grou	selected subnet ociated to a netw haging connectiv up instead of cre	t 'yoavopen work securit vity to this v eating a new	-6jsb4-worker-subnet (10.0 y group 'yoavopen-6jsb4-n rirtual machine via the exist v one here.	.32.0/19)' is already sg'. We recommen ing network securit
Accelerated	netwo	rking ①		The se	elected VM	size does not support ac	celerated network
Load balan	ncing						
You can pla	ce this	virtual machine in	the backend pool	of an existing	Azure load	balancing solution. Lea	rn more 🗗
Place this vi existing load	rtual m d balan	achine behind an cing solution?					

Click *review* and *create* and then *create* again and wait for the VM to start. When the machine will be created the following screen will appear. Click *Go-to resource*.

Ø	Your deployment is complete									
<u></u>	Deployment name: CreateVm-Canonical.UbuntuServer-18.04-LTS-2 Subscription: Excelero 20210123 Resource group: yoavopen-6jsb4-rg	Start time: 4/11/2021, 10:25:51 AM Correlation ID: 627fe7fb-eb85-4fee-bfb1-0107b68fc02f								
> Deployment details (Download)										
^	Next steps									
	Setup auto-shutdown Recommended									
	Monitor VM health, performance and network dependencies Recomm	ended								
	Run a script inside the virtual machine Recommended									
	Run a script inside the virtual machine Recommended Go to resource Create another VM									

If ssh times out, allow inbound port 22 to the VM. On the VM resource page, click *Networking* and add the rule.

🙍 NFS Networking	~~ X							
Virtual machine	ST Attach network interface	ద ^{ర్ర} Detach network interface						
Overview	nfs718							
Activity log	-							
R Access control (IAM)	ipconfig1 (Primary)	~						
Tags	Charles and the second second second	The second s	all and the second s					
Diagnose and solve problems	Virtual network/subnet: yoavog	pen-6jsb4-vnet/yoavopen-6jsb4-worker-subnet NIC Public IP: 23.97.147.27	NIC Private IP: 10.0.32.6 Acceler	ated networking: Disabled				
ettings	Inbound port rules Out	bound port rules Application security groups Load balancing						
Networking Connect	Network security group Impacts 2 subnets, 0 netw	yoavopen-6jsb4-nsg (attached to subnet: yoavopen-6jsb4-worker-subnet) ork interfaces					A	dd inbound port rule
Disks	Priority	Name	Port	Protocol	Source	Destination	Action	
Size	101	apiserver_in	6443	TCP	Any	Any	O Allow	
Security	500	a20536fcb48be4275833e3cabd8c9a2c-TCP-80-Internet	80	TCP	Internet	51.124.21.179	O Allow	
Advisor recommendations	501	a20536fcb48be4275833e3cabd8c9a2c-TCP-443-Internet	443	TCP	Internet	51.124.21.179	 Allow 	
Extensions	511	A Port_8080	22	TCP	Any	Any	 Allow 	
Continuous delivery	65000	AllowVnetInBound	Any	Any	VirtualNetwork	VirtualNetwork	O Allow	
Availability + scaling	65001	AllowAzureLoadBalancerInBound	Any	Any	AzureLoadBalancer	Any	O Allow	
Configuration	65500	DenyAllinBound	Any	Any	Any	Any	O Deny	
Identity								
Properties								
Locks								
ations								
astion								
uto-shutdown								
tkup								
saster recovery								
est + host updates								
entory								
nge tracking								
nfiguration management (
licies								
un command								
toring								
rsights								
Alerts								
Metrics 👻								

Add inbound security rule	×
yuavuper-ojsuw-risg	
aurra (0)	
	~
niy	
Source port ranges * ①	
Destination ①	
Any	~
Service ①	
SSH	\sim
Destination port ranges ①	
22	
Protocol	
Any	
TCP	
UDP	
○ ICMP	
Action	
Allow	
O Deny	
Priority * ①	
521	
Name *	
fdsfds	~
Description	
Description	

On the machine run:

```
sudo apt install -y nfs-kernel-server
sudo mkdir -p /opt/nvmesh/backups
sudo mkdir -p /opt/nvmesh/mongo
sudo chown -R nobody:nogroup /opt/nvmesh/backups/
sudo chown -R nobody:nogroup /opt/nvmesh/mongo/
sudo chmod 777 /opt/nvmesh/backups/
sudo chmod 777 /opt/nvmesh/mongo/
```

Edit /etc/exports and add (with root permissions):

/opt/nvmesh/backups 10.0.32.0/24(rw,sync,no_subtree_check)
/opt/nvmesh/mongo 10.0.32.0/24(rw,sync,no subtree check)

Finally, run the following:

```
sudo exportfs -a
sudo systemctl restart nfs-kernel-server
```

Run *ifconfig* to take the internal IP address of the machine and record it for future use.

3.6. Add a PV to the Cluster

Add a Shared Persistent Volume to the Cluster

Use the following YAML based on the NFS server created at the previous step. Change 10.0.32.6 to the internal IP recorded at the previous stage. If method other than NFS was used, then use the appropriate YAML for that method.

```
apiVersion: v1
kind: PersistentVolume
metadata:
name: data-volume-mongodb
 labels:
  role: mongo-for-nvmesh
spec:
 capacity:
   storage: 20Gi
 volumeMode: Filesystem
 accessModes:
   - ReadWriteOnce
 persistentVolumeReclaimPolicy: Recycle
 storageClassName: default
 nfs:
   server: 10.240.0.9
   path: /opt/nvmesh/mongo/
```

```
apiVersion: v1
kind: PersistentVolume
metadata:
name: nvmesh-backup-0
labels:
  role: nvmesh-backups
spec:
 capacity:
   storage: 5Gi
 volumeMode: Filesystem
 accessModes:
   - ReadWriteOnce
 persistentVolumeReclaimPolicy: Recycle
 storageClassName: default
 nfs:
   server: 10.240.0.9
```

path: /opt/nvmesh/backups

3.7. Install NVMesh Pods

The next step is to load the **NVMesh** objects to the cluster using the following YAML.

🛠 Use the default project.

TCP Version

```
apiVersion: nvmesh.excelero.com/v1
kind: NVMesh
metadata:
 name: cluster1
spec:
 core:
   version: 2.2.0-490
   tcpOnly: true
   configuredNICs: eth0
   azureOptimized: true
  csi:
   controllerReplicas: 1
   version: v1.1.4-7
 management:
   imageRegistry: registry.excelero.com
   mongoDB:
     replicas: 1
    replicas: 1
    version: 2.2.0
```

Infiniband Version

```
apiVersion: nvmesh.excelero.com/v1
kind: NVMesh
metadata:
   name: cluster1
spec:
   core:
    version: 2.2.0-423-ib2
    tcpOnly: false
    configuredNICs: ib0
    azureOptimized: true
   csi:
```

```
controllerReplicas: 1
version: v1.1.4-7
management:
    imageRegistry: registry.excelero.com
    mongoDB:
        replicas: 1
    replicas: 1
    version: 2.2.0
```

To validate, go to the *Workloads / Pods* page using the left menu. Check that the following pods are running or pending like in the following image.

Administration -	* -	You are logged in as a temporary administrative user. Update the <u>cluster OAuth configuration</u> to allow others to log in.								
₩ Administrator •	Project: default 🛛 👻									
Home 🗸	De de							_	_	
Overview	Pods							Create	e Pod	
Projects	▼ Filter ▼ Name ▼ Searc	h by name								
Search	Name 1	Status 1	Ready 1	Restarts 1	Owner 1	Memory 1	CPU 1	Created 1		
Explore	P mongo-0	C Running	1/1	0	SS mongo	88.7 MiB	0.005 cores	3 minutes ago	:	
Events		0 0 1				001117		0 • • •	•	
Operatore ¥	P nvmesn-csi-controller-0	C Running	4/4	0	SS nymesh-csi-controller	98.1 MIB	0.001 cores	S minutes ago	:	
	P nvmesh-management-0	Z Pending	0/0	0	SS nymesh-management	-	-	3 minutes ago	:	
OperatorHub	P nvmesh-operator-6b6f9f7f9-tjfhx	C Running	1/1	0	RS nymesh-operator-6b6f9f7f9	71.7 MiB	0.005 cores	Apr 11, 10:00 am	:	
Installed Operators										
Workloads 🗸										
Pods										
Deployments										
DeploymentConfigs										
StatefulSets										
Secrets										
ConfigMaps										
Cran Johs										
Jobs										
DaemonSets										
Take graphical screenshot										

To start *Client*, *Target*, and *Management* pods, label the OpenShift workers accordingly using the OpenShift CLI, as follows:

· Create an OC token: click kube:admin and then Copy login command

	\$ 1	Ð	•	kube:admin 🗸
You are logged in as a temporary administrative user. Update the <u>cluster OAuth configuration</u> to allow others to log in.			Copy logir	n command 🛛 🖻
			Language	preference
			Log out	
				Create Pod

• You may need to re-login with your cluster login/password, for instance if it timed out

• Click Display Token and copy the login command

Your API token is sha256~wP3TJpTLllVe7QzwchY3soZFMmDNuvRwKkYYisGhhD8
Log in with this token
oc logintoken====================================
Use this token directly against the API
curl -H "Authorization: Bearer sha256-wP3TJpTLllVe7QzwchY3soZFMmDNuvRwKkYYisGhhD8" "https://api.yoavopen.excelero.org:6443/apis/user.openshift.io/v1/users/~"
Request another token Logout

• On the local machine, run the login command

Note: "oc" must be the path to the command downloaded during cluster install. Also, answer "y" to the insecure prompt if requested.

- Run oc project default
- Run oc get nodes
- There should now be 3 workers and 3 masters
- Tag one of the workers as *Management* by running: oc label node <worker_name> nvmesh.e xcelero.com/nvmesh-management="". Change to the name from the previous stage).
- Now tag all workers as Client and Target using tags commands: oc label node <worker_nam
 e> nvmesh.excelero.com/nvmesh-client="" && oc label node <worker_name> nvme
 sh.excelero.com/nvmesh-target=""
- Go to the *Pods* page and validate that the *Client*, *Target*, and *Management* pods are up.

Name 1	Status 1	Ready 1	Restarts 1	Owner 1	Memory 1	CPU 1	Created 1	
P mongo-0	2 Running	1/1	0	SS mongo	-	-	🚱 3 minutes ago	:
P nvmesh-client-driver-container- 6kmqc	C Running	1/1	0	DS nvmesh-client-driver-container	-	-	🚱 a minute ago	÷
P nvmesh-client-driver-container-7bqhd	C Running	1/1	0	DS nymesh-client-driver-container	-	-	🔮 2 minutes ago	÷
P nvmesh-client-driver-container-thxkr	2 Running	1/1	0	DS nymesh-client-driver-container	-	-	🚱 a minute ago	ŧ
P nymesh-csi-controller-0	C Running	4/4	0	SS nymesh-csi-controller	-	-	🚱 Apr 28, 3:19 pm	÷
P nvmesh-csi-node-driver-g2nrr	2 Running	2/2	0	DS nymesh-csi-node-driver	-	-	🚱 a minute ago	:
P nvmesh-csi-node-driver-pdlkc	C Running	2/2	0	DS nymesh-csi-node-driver	-	-	🔮 2 minutes ago	÷
P nvmesh-csi-node-driver-x69lk	C Running	2/2	0	DS nymesh-csi-node-driver	-	-	🚱 a minute ago	÷
P nvmesh-management-0	2 Running	1/1	0	SS nymesh-management	-	-	🚱 3 minutes ago	:
P nvmesh-mcs-agent-bqx58	C Running	2/2	1	DS nymesh-mcs-agent	-	-	🚱 a minute ago	:
P nvmesh-mcs-agent-g428r	2 Running	2/2	1	DS nymesh-mcs-agent	-	-	2 minutes ago	÷
P nvmesh-mcs-agent-qmh2t	C Running	2/2	1	DS nymesh-mcs-agent	-	-	🚱 a minute ago	÷
P nvmesh-operator-c4fbcdd94-zg6rv	C Running	1/1	0	RS nvmesh-operator-c4fbcdd94	-	-	🚱 Apr 28, 3:18 pm	÷
P nvmesh-target-driver-container-5cgvj	2 Running	3/3	0	DS nymesh-target-driver-container	-	-	🚱 a minute ago	÷
nvmesh-target-driver-container- gwwrb	C Running	3/3	0	DS nvmesh-target-driver-container	-	-	🚱 a minute ago	:
P nvmesh-target-driver-container-tc22s	C Running	3/3	0	DS nymesh-target-driver-container	-	-	🚱 a minute ago	:

```
Excelero, Ltd.
```

3.8. Expose Management Routes

Add a *Route* to expose the *Management* pod UI into a public DNS using the following YAML. Replace yourcluster with your-domain.

```
kind: Route
apiVersion: route.openshift.io/v1
metadata:
 name: mgmt-gui
spec:
 host: ui-mgmt.apps.YOUR-CLUSTER.YOUR-DOMAIN
  to:
   kind: Service
   name: nvmesh-management-gui
   weight: 100
 port:
   targetPort: gui
  tls:
    termination: passthrough
    insecureEdgeTerminationPolicy: Redirect
  wildcardPolicy: None
```

The URL <u>https://ui-mgmt.apps.YOUR-CLUSTER.YOUR-DOMAIN</u> can be used login to the cluster.

If the OpenShift cluster is deployed on Azure, use the name of the Private DNS zone of your resource group.

4. Creating PVCs with NVMesh Storage

The following sections describe how to generate Persistent Volume Claims that will be stored on *NVMesh* volumes.

4.1. Format Drives

Use the official guide and format drives, typically all, in the cluster. See Format Drives.

```
Excelero, Ltd.
```

4.2. Create PersistentVolumeClaims

Following is an example YAML for creating a *RAID-1* volume named *nvmesh-fast-storage*.

```
apiVersion: v1
kind: PersistentVolumeClaim
metadata:
   name: nvmesh-fast-storage
spec:
   accessModes:
    - ReadWriteMany
   volumeMode: Block
   resources:
      requests:
      storage: 10Gi
   storageClassName: nvmesh-raid1
```

5. NVMesh OpenShift Operator on Azure

This section provides instructions for deploying *NVMesh* on Microsoft Azure.

5.1. Prerequisites

This section describes the prerequisites for deploying *NVMesh* on Microsoft Azure.

5.1.1. Resource Limits

Make sure your Azure subscription has at least the following resource limits:

- 1. Go to Microsoft Azure Subscriptions and choose your subscription
- 2. Choose Usage + quotas from the left sidebar



3. If any of the resource limits below are insufficient, see the table as reference, use the link at the top to **Request Quota Increase**

	«	Զ Request Quota Increase 🖒 Refresh					
🥏 Tags	^	You can use each Microsoft Azure resource	up to its quota. Each subscription has sepa	ate quotas and usage is tracked per subscrip	tion. If you reach a quota cap, you can reques	tan	Request Increase
Diagnose and solve problems		increase via Help + Support. Learn more					Request increase
Security		₽ Search	All service quotas	All providers	All locations V	Show all	~
Events	i.	Showing 1 to 100 of 5379 records.				No	grouping V

Component	Number of Components Required by Default	Default Azure Limit	Description
vCPUs	 DSv3 – 24. 8 each for 3 masters Infiniband: HBv3 – 360. 120 each for 3 workers or TCP: LSv2 – 64. 32 each for 2 workers DSv4 – 4 for the bootstrap machine 	20 per region	A default cluster requires 40 vCPUs, so you must increase the account limit. By default, each cluster creates the following instances: 1. 1 bootstrap

Excelero,	Ltd.
-----------	------

	machine, which is removed after installation. 2. 3 control plane machines. 3. 3 compute machines.
	As the bootstrap machine uses D4s_v3 machines with 4 vCPUs, the control plane machines use D8s_v3 virtual machines with 8 vCPUs and the worker machines use D4s_v3 machines with 4 vCPUs, a default cluster requires 40 vCPUs.
	The bootstrap node VM, which uses 4 vCPUs, is used only during installation.
	To deploy more worker nodes, enable autoscaling, deploy large workloads or use a different instance type,

Excelero, l	_td.
-------------	------

			2 subnets
Virtual Networks	1	1000 per region	Each default cluster requires a Virtual Network (VNet), which contains
			availability zones, the installation program places more than one control plane machine in the available zones.
			region contains fewer than 3
			availability
			with at least 3
			select a region
			availability for
			ensure high
			region. To
			availability
			across <u>all</u>
			machines
			and compute
			program
			installation
			By default, the
			required.
			deploy the
			cluster can
			ensure that the
			increase the

Interfaces			cluster requires 6 network interfaces. If additional machines are created or workloads deployed create load balancers, the cluster uses more network interfaces.
Network Security Groups		5000	Each cluster creates network security groups for each subnet in the VNet. The default cluster creates network security groups for the control plane and for the compute node subnets: <i>controlplane</i> : Allows the control plane machines to be reached on port 6443 from anywhere. <i>node</i> : Allows worker nodes to be reached from the Internet on ports 80 and 443.
Network Load Balancers	3	1000 per region	Each cluster creates the following load
Excelero, l	_td.		
-------------	------		
-------------	------		

		balancers: default – Public IP address that load balances requests to ports 80 and 443 across worker machines. internal – Private IP address that load balances requests to ports 6443 and 22623 across control plane machines. Public IP address that load balances requests to port 6443 across control plane machines. If applications create additional Kubernetes LoadBalancer service objects, the cluster will use additional
Public IP Addresses	3	Each of the 2 public load balancers uses a public IP address. The bootstrap machine also

		uses a public IP address so that SSH can be used to troubleshoot issues during installation. The IP address for the bootstrap node is used only during installation.
Private IP Addresses	7	The internal load balancer, each of the 3 control plane machines and each of the 3 worker machines each use a private IP address.

5.1.2. Roles and Permissions

The Microsoft Azure account must have the role **User Access Administrator** for the subscription.

To validate:

- 1. Go to Microsoft Azure Subscription and choose the subscription
- 2. On the left bar click Access control (IAM)
- 3. Choose "Role Assignments" and check if the user is shown under User Access Administrator

For additional information on how to assign roles, see Assign Azure roles using the Azure portal.

The user should also be an **Application Administrator**.

To validate:

- 1. Go to Microsoft Azure All users
- 2. Click the username
- 3. Click **Assigned Roles** in the left sidebar

If the user is not an **Application Administrator**, contact the Azure Admin to assign the role.

5.1.3. Public DNS Zone

A Public DNS Zone in Azure is also a prerequisite. Use the following steps, originally from the OpenShift tutorial, to create one.

- Identify your domain, or subdomain, and registrar. You can transfer an existing domain and registrar or obtain a new one through Azure or another source.
 For more information about purchasing domains through Azure, see <u>Buy a custom domain name for Azure App Service</u> in the Azure documentation.
- If you are using an existing domain and registrar, migrate its DNS to Azure. See <u>Migrate an active</u> <u>DNS name to Azure App Service</u> in the Azure documentation.
- Configure DNS for your domain. Follow the steps in the <u>Tutorial: Host your domain in Azure DNS</u> in the Azure documentation to create a public hosted zone for your domain or subdomain, extract the new authoritative name servers, and update the registrar records for the name servers that your domain uses.

Use an appropriate root domain, such as openshiftcorp.com, or subdomain, such as clusters.openshiftcorp.com.

• If you use a subdomain, follow your company's procedures to add its delegation records to the parent domain.

5.1.4. Azure CLI

Azure CLI is also a prerequisite. Following these steps to install it.

- 1. To install Azure CLI on a local machine, see Install the Azure CLI for Linux manually
- 2. Create a user or login to an existing one on the Red Hat portal https://cloud.redhat.com/
- Follow step 1 only as described here, <u>https://cloud.redhat.com/openshift/install/azure/installer-provisioned</u>. Download the OpenShift CLI (OC) and openshift-install and record the pull secret for later. Untar OC and openshift-install using tar xzvf <filenames>.

5.2. OpenShift Cluster on Azure

This section describes how to deploy OpenShift cluster on Azure and how to subsequently access it.

For setups working with Infiniband mode, change the definitions manually as described in section Infiniband Only.

```
Excelero, Ltd.
```

5.2.1. Deploying the Cluster

Connect to Azure using its CLI.

- 1. Most often this can be done from a local computer shell.
- 2. Use az login to begin the connection.
- 3. Follow the shell steps to complete the login process.

Verify that the expected Azure subscriptions are accessible.

1. Use az account list --refresh to see all available subscriptions, for example as follows.

```
1 [
 2
    {
 3
          "cloudName": "AzureCloud",
 4
          "homeTenantId": "xxxxx-x-x-x-x-x-x-,
         "id": "xxxxxxxxxxxxxxxxxxxxxxx,
 5
 6
         "isDefault": true,
 7
         "managedByTenants": [],
         "name": "Just a name",
 8
          "state": "Enabled",
 9
         "tenantId": "xxxxx-xxxxx-xxxx-xxxx,
10
11
          "user": {
            "name": "xxxx@excelero.com",
12
            "type": "user"
13
          }
14
15
        }
16
      1
```

2. Use az account set -s <id> to choose a specific subscription.

Run az account show.

1. <u>Record the values of tenantId and id for future use</u>.

Create a service principal, which is needed for each cluster using az ad sp create-for-rbac --rol e Contributor --name <service_principal_name>.

- 1. Make a note of the values for appId and password from the output for future use.
- 2. **Note:** The error, "When using this permission, the backing application of the service principal being created must in the local tenant" seems like a transient bug. Rerun the command until it works.

Grant permissions to the created Server Principal using the ${\tt appId}$ recorded above.

- az role assignment create --role "User Access Administrator" --assignee-obje ct-id \$(az ad sp show --id <service-principal-name> -o tsv --query objectId)
- 2. az ad app permission add --id <appId> --api 00000002-0000-0000-c000-00000000 0000 --api-permissions 824c81eb-e3f8-4ee6-8f6d-de7f50d565b7=Role
- 3. az ad app permission grant --id <appId> --api 00000002-0000-0000-c000-000000 000000

Choose one of the following YAMLs, TCP YAML or Infiniband YAML, and save it in the same folder as openshift-installer binary and name it install-config.yaml.

Example YAML for TCP-based environments

```
apiVersion: v1
baseDomain: <your base dns>
compute:
- architecture: amd64
 hyperthreading: Enabled
 name: worker
 platform:
    azure:
     type: Standard L32s v2
     osDisk:
       diskSizeGB: 512
     zones:
      - "1"
 replicas: 3
controlPlane:
  architecture: amd64
 hyperthreading: Enabled
 name: master
 platform: { }
 replicas: 3
metadata:
  creationTimestamp: null
  name: <your desired cluster name>
networking:
 clusterNetwork:
  - cidr: 10.128.0.0/14
   hostPrefix: 23
 machineNetwork:
 - cidr: 10.0.0/16
 networkType: OpenShiftSDN
  serviceNetwork:
  - 172.30.0.0/16
```

```
platform:
    azure:
    baseDomainResourceGroupName: nvmeshrg
    cloudName: AzurePublicCloud
    outboundType: Loadbalancer
    region: westeurope
publish: External
sshKey: <your_public_ssh_key(not_path)>
pullSecret: '<your_pull_secret(not_path)>'
```

Example YAML for Infiniband-based environments

```
apiVersion: v1
baseDomain: <your base dns>
compute:
- architecture: amd64
 hyperthreading: Enabled
 name: worker
 platform:
   azure:
     type: Standard HB120rs v3
     osDisk:
      diskSizeGB: 512
     zones:
     - "1"
 replicas: 0
controlPlane:
 architecture: amd64
 hyperthreading: Enabled
 name: master
 platform: { }
 replicas: 3
metadata:
 creationTimestamp: null
 name: <your desired cluster name>
networking:
 clusterNetwork:
  - cidr: 10.128.0.0/14
   hostPrefix: 23
 machineNetwork:
 - cidr: 10.0.0/16
 networkType: OpenShiftSDN
  serviceNetwork:
```

```
- 172.30.0.0/16
platform:
    azure:
    baseDomainResourceGroupName: nvmeshrg
    cloudName: AzurePublicCloud
    outboundType: Loadbalancer
    region: westeurope
publish: External
sshKey: <your_public_ssh_key(not_path)>
pullSecret: '<your_pull_secret(not_path)>'
```

No workers are created when working with Infiniband. This is on purpose, as openshiftinstall does not supported the availability set feature. Workers will be created later oo.

Edit the YAML file filling in the following.

- 1. your_base_dns the public base DNS domain as configured in azure, for example excelero.org.
- 2. Set the number of workers or *NVMesh* nodes by changing 3 to any number bigger than 3.
- 3. your_desired_cluster_name.
- 4. your_public_ssh_key (not_path) copy and paste a public key that will be installed on all openshift nodes.
- 5. your_pull_secret (not_path) **keep the quotes** and replace the variable with copy-paste of the pull secret you download at the prerequisite stage.
- 6. region can be any region from the following list that has enough limits as described in the prerequisite.
 - australiacentral (Australia Central)
 - australiaeast (Australia East)
 - australiasoutheast (Australia South East)
 - brazilsouth (Brazil South)
 - canadacentral (Canada Central)
 - canadaeast (Canada East)
 - centralindia (Central India)
 - centralus (Central US)
 - eastasia (East Asia)
 - eastus (East US)
 - eastus2 (East US 2)
 - francecentral (France Central)
 - germanywestcentral (Germany West Central)
 - japaneast (Japan East)
 - japanwest (Japan West)
 - koreacentral (Korea Central)
 - koreasouth (Korea South)

- northcentralus (North Central US)
- northeurope (North Europe)
- norwayeast (Norway East)
- southafricanorth (South Africa North)
- southcentralus (South Central US)
- southeastasia (Southeast Asia)
- southindia (South India)
- switzerlandnorth (Switzerland North)
- uaenorth (UAE North)
- uksouth (UK South)
- ukwest (UK West)
- westcentralus (West Central US)
- westeurope (West Europe)
- westindia (West India)
- westus (West US)
- westus2 (West US 2)

Run rm -f ~/.azure/osServicePrincipal.json to delete any previous service principal configuration on the local machine.

Run ./openshift-install create cluster --dir=./ --log-level=debug. The process should take around 50 minutes and will provide an interactive shell.

- 1. Platform \rightarrow choose azure
- 2. subscription id \rightarrow paste the id recorded above
- 3. tenant id \rightarrow paste the tenantId recorded above
- 4. service principal client id \rightarrow paste appId recorded above
- 5. service principal client secret \rightarrow paste password recorded above

Accelerate worker machine NICs once the cluster is up.

- 1. Go to Microsoft Azure Resource Groups
- 2. Click the resource group with the cluster name defined
- 3. Search for **Network Interface** resources named: -xxxx-worker-region-xxxxx-nic.
- 4. Click on the NIC and then click **Enabled accelerated networking** at the top.

 Following are some known errors:
 ERROR Error: authorization.RoleAssignmentsClient#Get: Failure responding to request: StatusCode=404 — Original Error: autorest/azure: Service returned an error. Status=404 Code="RoleAssignmentNotFound" Message="The role assignment '9f6023cc-81c9-7914-5c89-03cc7ea74ea1' is not found."
 ERROR
 ERROR on ../../tmp/openshift-install-935734395/main.tf line 161, in resource "azurerm_role_assignment" "main": ERROR 161: resource "azurerm_role_assignment" "main" this can randomly after creating the cluster machines role_assignment: fix immediate read after write issue by dlamotte · Pull Request #9698 · terraform-providers/terraform-provider-azurerm due to a TF provider bug which was fixed. If happen destroy the cluster and rerun:

If there are errors, run ./openshift-install destroy cluster and revert to the create cluster step.

5.2.2. Accessing the Cluster

When the install finishes, which typically takes around 50 minutes, output such as follows is expected.

DEBUG Cluster is initialized INFO Waiting up to 10m0s for the openshift-console route to be created... DEBUG Route found in openshift-console namespace: console DEBUG OpenShift console route is admitted INFO Install complete! INFO To access the cluster as the system:admin user when using 'oc', run 'export KUBECONFIG=/home/YOURUSER/auth/kubeconfig' INFO Access the OpenShift web-console here: https://console-openshift-console.apps.YOURCLUSTER.YOURDOMAIN INFO Login to the console with user: "xxxx", and password: "gdfklgdflgdfgfd" DEBUG Time elapsed per stage:

It should now be possible to login to the cluster using the link, user and password shown.

5.2.3. Infiniband Only

To use Infiniband mode, create the worker's VMs in the same *Availability Set* so that they have the same Infiniband pkey critical for Infiniband communications. This is not possible from openshift-installer. Instead, an ARM template is used.

- 1. Go to your openshift-install folder location and run ./openshift-install create ignition-co nfigs.
- 2. Run cat ./worker.ign | base64 | tr -d '\n' > ignition base64.
- Run cat terraform.tfvars.json | grep cluster_id and record your cluster_id/base name for future use.
- 4. Go to https://portal.azure.com/#create/Microsoft.Template and click **Build your own template in the editor**
- 5. Copy and paste the following YAML and click **save**.

```
{
  "$schema" : "https://schema.management.azure.com/schemas/2015-01-01/deploymentT
emplate.json#",
  "contentVersion" : "1.0.0.0",
  "parameters" : {
    "baseName" : {
      "type" : "string",
      "minLength" : 1,
      "metadata" : {
        "description" : "Base name to be used in resource names (usually the clus
ter's Infra ID)"
      }
    },
    "workerIgnition" : {
      "type" : "string",
      "metadata" : {
        "description" : "Ignition content for the worker nodes"
      }
    },
    "numberOfNodes" : {
      "type" : "int",
      "defaultValue" : 3,
      "minValue" : 1,
      "maxValue" : 30,
      "metadata" : {
        "description" : "Number of OpenShift compute nodes to deploy"
      }
    },
```

```
"sshKeyData" : {
      "type" : "securestring",
      "metadata" : {
        "description" : "SSH RSA public key file as a string"
      }
    },
    "availabilitySetName": {
    "type" : "string",
      "metadata" : {
        "description" : "Availability Set Name"
      1
    },
    "nodeVMSize" : {
      "type" : "string",
      "defaultValue" : "Standard HB120rs v3",
      "allowedValues" : [
        "Standard D2s v3",
       "Standard D4s v3",
        "Standard HB120rs v3"
      ],
      "metadata" : {
        "description" : "The size of the each Node Virtual Machine"
 },
 "variables" : {
    "location" : "[resourceGroup().location]",
    "virtualNetworkName" : "[concat(parameters('baseName'), '-vnet')]",
    "virtualNetworkID" : "[resourceId('Microsoft.Network/virtualNetworks', variab
les('virtualNetworkName'))]",
    "nodeSubnetName" : "[concat(parameters('baseName'), '-worker-subnet')]",
    "nodeSubnetRef" : "[concat(variables('virtualNetworkID'), '/subnets/', variab
les('nodeSubnetName'))]",
    "infraLoadBalancerName" : "[parameters('baseName')]",
    "sshKeyPath" : "/home/capi/.ssh/authorized keys",
    "identityName" : "[concat(parameters('baseName'), '-identity')]",
    "imageName" : "[concat(parameters('baseName'), '')]",
    "copy" : [
        "name" : "vmNames",
        "count" : "[parameters('numberOfNodes')]",
        "input" : "[concat(parameters('baseName'), '-worker-', variables('locatio
n'), '-', copyIndex('vmNames', 1))]"
```

```
},
  "resources" : [
        {
                "type": "Microsoft.Compute/availabilitySets",
                "name": "[parameters('availabilitySetName')]",
                "apiVersion": "2019-03-01",
                "location": "[variables('location')]",
                "properties": {
                        "platformFaultDomainCount": "3",
                        "platformUpdateDomainCount": "5"
                },
                "sku": {
                        "name": "Aligned"
        }
       },
    {
      "apiVersion" : "2019-05-01",
      "name" : "[concat('node', copyIndex())]",
      "type" : "Microsoft.Resources/deployments",
      "copy" : {
        "name" : "nodeCopy",
        "count" : "[length(variables('vmNames'))]"
      },
      "dependsOn" : [
        "[resourceId('Microsoft.Compute/availabilitySets', concat(parameters('ava
ilabilitySetName')))]"
      ],
      "properties" : {
        "mode" : "Incremental",
        "template" : {
          "$schema" : "http://schema.management.azure.com/schemas/2015-01-01/depl
oymentTemplate.json#",
          "contentVersion" : "1.0.0.0",
          "resources" : [
            {
              "apiVersion" : "2018-06-01",
              "type" : "Microsoft.Network/networkInterfaces",
              "name" : "[concat(variables('vmNames')[copyIndex()], '-nic')]",
              "location" : "[variables('location')]",
              "properties" : {
                "ipConfigurations" : [
                    "name" : "pipConfig",
```

```
"properties" : {
                      "privateIPAllocationMethod" : "Dynamic",
                      "subnet" : {
                        "id" : "[variables('nodeSubnetRef')]"
                      },
                      "loadBalancerBackendAddressPools" : [
                        {
                          "id" : "[resourceId('Microsoft.Network/loadBalancers/ba
ckendAddressPools',variables('infraLoadBalancerName'), variables('infraLoadBalanc
erName'))]"
                        }
                        1
                    }
                1
              }
            },
              "apiVersion" : "2018-06-01",
              "type" : "Microsoft.Compute/virtualMachines",
              "name" : "[variables('vmNames')[copyIndex()]]",
              "location" : "[variables('location')]",
              "tags" : {
                "kubernetes.io-cluster-ffranzupi": "owned"
              },
              "identity" : {
                "type" : "userAssigned",
                "userAssignedIdentities" : {
                  "[resourceID('Microsoft.ManagedIdentity/userAssignedIdentitie
s/', variables('identityName'))]" : {}
                }
              },
              "dependsOn" : [
                "[concat('Microsoft.Network/networkInterfaces/', concat(variable
s('vmNames')[copyIndex()], '-nic'))]"
              ],
              "properties" : {
                "hardwareProfile" : {
                  "vmSize" : "[parameters('nodeVMSize')]"
                },
                "osProfile" : {
                  "computerName" : "[variables('vmNames')[copyIndex()]]",
                  "adminUsername" : "capi",
                  "customData" : "[parameters('workerIgnition')]",
```

```
"linuxConfiguration" : {
                    "disablePasswordAuthentication" : true,
                    "ssh" : {
                      "publicKeys" : [
                        {
                          "path" : "[variables('sshKeyPath')]",
                          "keyData" : "[parameters('sshKeyData')]"
                        }
                      1
                    }
                  }
                },
                "storageProfile" : {
                  "imageReference": {
                    "id": "[resourceId('Microsoft.Compute/images', variables('ima
geName'))]"
                  },
                  "osDisk" : {
                    "name": "[concat(variables('vmNames')[copyIndex()],' OSDis
k')]",
                    "osType" : "Linux",
                    "createOption" : "FromImage",
                    "managedDisk": {
                      "storageAccountType": "Premium LRS"
                    },
                    "diskSizeGB": 512
                  }
                },
                "networkProfile" : {
                  "networkInterfaces" : [
                    {
                      "id" : "[resourceId('Microsoft.Network/networkInterfaces',
concat(variables('vmNames')[copyIndex()], '-nic'))]",
                      "properties": {
                        "primary": true
                      }
                    }
                },
            "availabilitySet": {
                "id": "[resourceId('Microsoft.Compute/availabilitySets', paramete
rs('availabilitySetName'))]"
            }
```

```
}
}
}
}
}
```

Now fill in the following elements.

- Subscription
- Resource Group
- Region Choose the same region used for the OpenShift cluster
- Base Name The cluster_id recorded above
- Worker Ignition The content of the ignition_base64 file created above
- Number Of Nodes 3
- Ssh Key Data the public ssh key itself
- Availability Set Name choose any name
- Node VM Size choose Standard_HB120rs_v3

Home >	
Custom deployment Deploy from a custom template	
Select a template Basics Review +	- create
Template	
Customized template 2 resources	Edit template Edit parameters
Project details	
Select the subscription to manage deployed manage all your resources.	d resources and costs. Use resource groups like folders to organize and
Subscription * ①	Excelero 20210123 V
Resource group * ①	hpc-ocp-nvmesh32-jsv2j-rg V Create new
Instance details	
Region * (i)	West Europe
Base Name * ①	hpc-ocp-nvmesh32-jsv2j 🗸
Worker Ignition * ①	eyJpZ25pdGlvbil6eyJjb25maWciOnsibWVyZ2UiOlt7InNvdXJjZSI6Imh0 🗸
Number Of Nodes ①	3
Ssh Key Data * ①	····· ✓
Availability Set Name *	example 🗸
Node VM Size ①	Standard_HB120rs_v3 V

Click *Review+Create* and then *Create*.

When the creation process ends, accept the new workers VMs using the OC CLI.

1. Create the oc token, click *kube:admin* and then copy the login command.



You may need to re-login with the cluster login/password if it timed out. Click *Display Token* and copy the login command.

zoom)	
Your API token is	
sha256~wP3TJpTLllV	7QzwchY3soZFMmDNuvRwKkYYisGhhD8
Log in with this token	
oc logintoken=	server=https://api.yoavopen.excelero.org:6443
Use this token directly against the	PI
curl -H "Authorization:	Bearer sha256-wP3TJpTLllVe7QzwchY3soZFMmDNuvRwKkYYisGhhD8" "https://api.yoavopen.excelero.org:6443/apis/user.openshift.io/v1/users/~"
Request another token	
Logout	

On a local machine, run the login command. Note: the "oc" command should be in the standard command PATH from the cluster install. Also, you may need to answer "y" to the insecure prompt.

- 1. Run oc project default
- 2. Run oc get nodes

Use the following link which describes how to accept new nodes to OpenShift cluster: <u>https://docs.openshift.com/container-platform/4.7/installing/installing_azure/installing-azure-user-infra.html#installation-approve-csrs_installing-azure-user-infra</u>, number of new nodes should match the number of workers.

The **NVMesh** tracer requires 5 * 4 * num_of_cpus threads process IDs, increase the PID limit of the workers. Use the following guide to increase it to 4096 to be on the safe side, <u>How to change the value of pids_limit in OpenShift 4.x</u>

6. NVMesh on Azure Kubernetes Service

For an overview of Azure Kubernetes Service, hereon AKS, see this link.

The following steps outline how to initialize an AKS cluster for use with *NVMesh*. Beyond that, the instructions from the previous sections apply.

Specifically, see the prerequisites for <u>NVMesh OpensShift Operator on Azure Prerequisites</u>. All sections apply, except that the Azure CLI should be built-in already.

6.1. Quick Summary

Action	Command
Login	az login
Verify login	az account listrefresh
Optional: choose a different account	az account set -s <id></id>
Create a resource group	az group createname <resourcegroupname>location <region></region></resourcegroupname>
Optional: install kubectl	sudo az aks install-cli
Create the AKS cluster	<pre>az aks createresource-group <resourcegroupname>name <clusternam e="">node-count <node-count>generate-ssh-keys</node-count></clusternam></resourcegroupname></pre>
Update local credentials for the newly created cluster	az aks get-credentialsresource-group <resourcegroupname>name <clu sterName></clu </resourcegroupname>
Verify AKS cluster creation	kubectl get nodes
Create a proximity placement group	az ppg create -n <ppgname> -g <resourcegroupname> -l <region> -t standa rd</region></resourcegroupname></ppgname>
Check node availability by zone	az vm list-skus -l eastus2zonesize "Standard_L48s_v2"
Deploy a node pool for Targets	<pre>az aks nodepool addresource-group myResourceGroupcluster-name myA KSClustername <nodepool name="">node-vm-size Standard_L48s_v2nod e-count <node-count>ppg <myppgresourceid>labels nvmesh.excelero.c om/nvmesh-management="" nvmesh.excelero.com/nvmesh-client="" nvmesh.exc elero.com/nvmesh-target=""zones <zone-id></zone-id></myppgresourceid></node-count></nodepool></pre>

Import YAMLs with NVMesh 2.4 operator secrets	
Install and access the <i>NVMesh 2.4</i> operator	git clone git@gitlab.excelero.com:excelero/openshift-operator.git cd openshift-operator
Deploy the <i>NVMesh 2.4</i> operator	kubectl apply -f deploy/
Verify the operator deployment	kubectl get pods
Deploy NVMesh 2.4 pods	<pre>kubectl apply -f deploy/samples/nvmesh/nvmesh_v1_AKS_tcp.yaml</pre>
Verify the pods deployment	kubectl get podswatch or watch -d kubectl get pods -o wide
Generate an NVMesh 2.4 volume	kubectl apply -f <volume.yaml></volume.yaml>
List PVCs	kubectl get pvcs
List PVs	kubectl get pvs
Performance Tuning	<pre>kubectl edit configmap nvmesh-core-config - edit the configuration kubectl delete ds nvmesh-client nvmesh-target nvmesh-mcs-agent - apply the configuration</pre>

6.2. Deploying the AKS Cluster

It is assumed that the user is acquainted with <u>Azure CLI</u>.

Login via the Azure CLI

```
az login
```

Follow the instructions in the shell to complete the login.

Verifying access to the Azure subscriptions

az account list --refresh

This will show all available subscriptions, for example, as follows.



Use az account set -s <id> to choose a specific subscription.

Creating a Resource Group

az group create --name <resourceGroupName> --location <region>

Example output follows:

```
3 ~ {
      "id": "/subscriptions/cf41518e-baf3-4748-9ebd-7b2c35f34207/resourceGroups/myResourceGroup",
 4
      "location": "eastus",
5
      "managedBy": null,
 6
      "name": "myResourceGroup",
7
8 ∨ "properties": {
       "provisioningState": "Succeeded"
9
      },
10
     "tags": null,
11
     "type": "Microsoft.Resources/resourceGroups"
12
13
     }
```

Creating a Proximity Placement Group

az ppg create -n <ppgName> -g <resourceGroupName> -l <region> -t standard

Creating an AKS Cluster

```
az aks create --resource-group <resourceGroupName> --name <clusterName> --node-co
unt 3 --generate-ssh-keys --ppg <ppgResourceID>
```

If kubectl is not installed, it can be easily installed using:

```
sudo az aks install-cli
```

To verify that it was created, use:

```
kubectl get nodes
```

6.2.1. Login via the Azure CLI

az login

Follow the instructions in the shell to complete the login.

6.2.2. Verify Azure Subscription Access

az account list --refresh

This will show all available subscriptions, for example, as follows.

```
1 [
    {
2
         "cloudName": "AzureCloud",
3
         "homeTenantId": "xxxxx-x-x-x-x-x-x-,
4
         "id": "xxxxxxxxxxxxxxxxxxxxxxx,
5
         "isDefault": true,
6
         "managedByTenants": [],
7
         "name": "Just a name",
8
         "state": "Enabled",
9
         "tenantId": "xxxxx-xxxxx-xxxx-xxxx",
10
         "user": {
11
           "name": "xxxx@excelero.com",
12
           "type": "user"
13
         }
14
15
       }
16
      ]
```

Use az account set -s <id> to choose a specific subscription.

6.2.3. Create a Resource Group

az group create --name <resourceGroupName> --location <region>

Example output follows:

```
3 ~ {
      "id": "/subscriptions/cf41518e-baf3-4748-9ebd-7b2c35f34207/resourceGroups/myResourceGroup",
4
      "location": "eastus",
5
      "managedBy": null,
 6
7
      "name": "myResourceGroup",
8 ∨ "properties": {
      "provisioningState": "Succeeded"
9
10
     },
     "tags": null,
11
     "type": "Microsoft.Resources/resourceGroups"
12
13
     }
```

6.2.4. Create the Cluster

```
az aks create --resource-group <resourceGroupName> --name <clusterName> --node-co
unt <node-count> --generate-ssh-keys
```

At a minimum, node-count should be 3.

Update the local credentials to match the newly created cluster using:

az aks get-credentials --resource-group <resourceGroupName> --name <clusterName>

If kubect1 is not installed, it can be easily installed using:

```
sudo az aks install-cli
```

To verify that the cluster was created, use:

kubectl get nodes

6.3. Deploying NVMesh on AKS

6.3.1. Set up Repository Access

To access the *NVMesh* repository, import access credentials.

- 1. Obtain YAMLs containing the required secrets for repository access from <u>sales@excelero.com</u>.
- 2. Import the secrets YAMLs, see Installing YAMLs.

There are two secret YAMLs.

- The first provides access to Excelero's docker registry
- The second provides access to Excelero's RPM repositories

6.3.2. Deploy Node Pool for Targets

Targets are deployed using a node pool.

They can be either in availability zone or across two.

A PPG (proximity placement group) is needed per AZ (availability zone) used.

To create the PPG, use:

az ppg create -n <ppgName> -g <resourceGroupName> -l <region> -t standard

Then deploy a node pool per AZ with the PPG id returned from the previous command, as follows:

az aks nodepool add --resource-group myResourceGroup --cluster-name myAKSCluster --name <nodepool name> --node-vm-size Standard_L48s_v2 --node-count <node-count> --ppg <myPPGResourceID> --labels nvmesh.excelero.com/nvmesh-management="" nvmes h.excelero.com/nvmesh-client="" nvmesh.excelero.com/nvmesh-target="" --zones <zon e-id>

The node count should be 4 for a single AZ.

For cross-AZ, the node count should be 2 for each AZ. To ensure failover, add to the node pool another node of any type that will be used as an arbiter. Contact <u>Excelero Technical Support</u> for more in-depth instructions for ensuring failover.

For more storage, simply add additional node pools.

To know in which zones there are nodes of this type, use:

```
az vm list-skus -l eastus2 --zone --size "Standard L48s v2"
```

This will provide a response, see the following example excerpt, that lists the zones where the nodes are available.

```
"locationInfo": [
    {
        "location": "eastus2",
        "zoneDetails": [
        {
            "Name": [
            "3",
```

```
"2",
         "1"
        ],
        "capabilities": [
         {
          "name": "UltraSSDAvailable",
          "value": "True"
         }
       ],
       "name": null
    }
   ],
   "zones": [
     "3",
     "2",
     "1"
   ]
  }
],
"locations": [
 "eastus2"
],
"name": "Standard L48s v2",
"resourceType": "virtualMachines",
"restrictions": [],
"size": "L48s v2",
"tier": "Standard"
```

6.3.3. Get the NVMesh Operator

To obtain the *NVMesh* operator, run the following command

git clone git@gitlab.excelero.com:excelero/openshift-operator.git

Upon completion, a new directory name openshift-operator will contain files for operator deployment.

6.3.4. Deploy the NVMesh Operator

To deploy the *NVMesh* operator, use:

kubectl apply -f deploy/

Then, verify that the operator pods have been created using:

kubectl get pods

For example:

[tomzan@localhost openshift-operator]\$ kubectl get pods				
NAME	READY	STATUS	RESTARTS	AGE
nvmesh-operator-8548f59f4c-qcn2h	1/1	Running	0	24s
6.3.5. Deploy NVMesh Pods

Deploying the pods implementing *NVMesh* is typically done using the following command from the nvmeshoperator directory mentioned in the previous sections.

```
kubectl apply -f deploy/samples/nvmesh/nvmesh_v1_AKS_tcp.yaml
```

The built-in sample deploys using PremiumSSD managed disks for storing system configuration information. Other than changing the cluster name, it is recommended to contact <u>Excelero Technical Support</u> for any other changes.

Verify the pods have started using the following command. It may take a few minutes.

```
kubectl get pods --watch
```

or using

```
watch -d kubectl get pods -o wide
```

Sample output:

Server. / mb_example, openantic operatory ,	ubeett get	pous	
NAME READY	STATUS	RESTARTS	AGE
mongo-0 1/1	Running	0	33m
nvmesh-client-dp84f 1/1	Running	0	85s
nvmesh-client-tj9pw 1/1	Running	0	98s
nvmesh-client-zvmq2 1/1	Running	0	92s
nvmesh-csi-controller-0 4/4	Running	0	33m
nvmesh-csi-node-driver-2rgtx 2/2	Running	0	85s
nvmesh-csi-node-driver-92cn6 2/2	Running	0	92s
nvmesh-csi-node-driver-98v9b 2/2	Running	0	98s
nvmesh-management-0 1/1	Running	0	33m
nvmesh-mcs-agent-ffbls 2/2	Running	0	91s
nvmesh-mcs-agent-kdtsq 2/2	Running	0	85s
nvmesh-mcs-agent-ltx7q 2/2	Running	0	98s
nvmesh-operator-8548f59f4c-n4cmg 1/1	Running	0	33m
nvmesh-target-kk8gh 3/3	Running	0	73s
nvmesh-target-vcbd9 3/3	Running	0	61s
nvmesh-target-zpmbt 3/3	Running	0	67s

6.3.6. Create PVCs (Persistent Volume Claims)

Use the following command to create a PVC

```
kubectl apply -f <volume.yaml>
```

For example:

kubectl apply -f raid10-volume.yaml

For non-protected volumes, use a YAML such as this:

```
server:~/AKS_example$ cat raid0-volume.yaml
apiVersion: v1
kind: PersistentVolumeClaim
metadata:
   name: block-pvc-r0
spec:
   accessModes:
    - ReadWriteMany
volumeMode: Block
resources:
   requests:
    storage: 10Gi
storageClassName: nvmesh-raid0
```

The following example is for protected volumes:

```
server:~/AKS_example$ cat raid1-volume.yaml
apiVersion: v1
kind: PersistentVolumeClaim
metadata:
   name: block-pvc
spec:
   accessModes:
    - ReadWriteMany
volumeMode: Block
```

```
resources:
    requests:
    storage: 10Gi
storageClassName: nvmesh-raid1
```

The following example is for protected volumes with higher performance by using more drives in parallel:

```
server:~/AKS_example$ cat raid10-volume.yaml
apiVersion: v1
kind: PersistentVolumeClaim
metadata:
  name: block-pvc-r10
spec:
  accessModes:
    - ReadWriteMany
  volumeMode: Block
  resources:
    requests:
    storage: 10Gi
storageClassName: nvmesh-raid10
```

After creating one PVC of each of the examples, verification will show the following:

```
server:~/AKS example$ kubectl get pvc
NAME
                           STATUS
                                    VOLUM
Ε
                                   CAPACITY ACCESS MODES STORAGECLAS
S
     AGE
backups-nvmesh-management-0
                           Bound
                                   nvmesh-backu
p-0
                            5Gi
                                     RWO
                                                    default
                                                                     43h
block-pvc
                           Bound
                                    pvc-632172ae-5ac9-49f3-8cba-e63edc283c2
a 10Gi
                           nvmesh-raid1 40h
            RWX
block-pvc-r0
                           Bound
                                   pvc-7fc781e7-e744-4f0e-bac2-ec272c96462
2 10Gi
                           nvmesh-raid0 23h
            RWX
block-pvc-r10
                           Bound
                                    pvc-017fa85e-ce4c-4ff5-96a4-a02d0b1c2cc
5 10Gi
          RWX
                           nvmesh-raid10 23h
data-volume-mongo-0
                           Bound data-volume-mongod
                       20Gi
b
                                RWO
                                              default
                                                               43h
```

6.4. Performance Tuning

Performance tuning and changing other configuration parameters is often done via /etc/modprobe.d files.

These parameters are typically set in the YAML used to deploy the node pool *Targets*, but they may not to be altered later.

In the AKS environment, use the following command to edit the configuration parameters typically tuned via options in such files:

```
kubectl edit configmap nvmesh-core-config
```

Once edited, they are applied by restarting the **NVMesh 2.4** pods using:

```
kubectl delete ds nvmesh-client nvmesh-target nvmesh-mcs-agent
```